



RZR SHIFT HANDLE INSTRUCTIONS

For technical support contact Joker Machine

2245 Kiowa Blvd N. Ste. 100, Lake Havasu City, AZ 86403

PHONE: 909-596-9690, FAX: 909-596-9693

sales@jokermachine.com, www.jokermachine.com

TOOLS NEEDED

- 3mm Hex Driver/T-handle
- Blue Loctite

INSTALLATION

1. Remove stock shift knob
2. Install Joker Shifter to shift lever using blue loctite on 6mm set screw

