

HEADSET HANGER BRACKET

Part No. 60-150 to 60-151

For technical support contact Joker Machine

2245 Kiowa Blvd N. Ste. 100, Lake Havasu City, AZ 86403 PHONE: 909-596-9690, FAX: 909-596-9693 sales@jokermachine.com, www.jokermachine.com

TOOLS NEEDED:

- 5mm Hex Driver
- 4mm Hex Driver
- Medium Strength Thread Locker

Installation

NOTE: Use medium strength thread locker on all hardware

- 1. Clean area where the clamp is going to be mounted.
- 2. Install clamp (clamp is pre-assembled with 25mm long screw)
 - Use M6 x 25mm socket cap screw on 1 3/4" roll cages.
 - Use M6 x 30mm socket cap screw on 1 7/8" roll cages.

NOTE: Hanger bracket can mounted side to side or front to back.

3. Install hanger bracket with M6 x 14mm button head screw.

