

N O V O L I N K

Novolink™ Battery Operated Decorative LED String Lights

Thank you for purchasing the Novolink battery-operated decorative LED string light. This environmentally responsible, energy-efficient string light will create starry ambience for home decoration both indoors and outdoors (Battery not included.)

Important Safety Instructions: (Please Read Before Using Product)

- Do not step on or drive over the control box containing the battery.
- Do not submerge in water.
- Never operate this light if it has a damaged cord or plug.
- This product is not a toy. For decorative use only.
- For both outdoor and indoor use.
- Do not repair or modify.
- This product is not intended for use in extreme weather conditions. Freezing temperatures can damage the product. Move the lights indoors during these conditions.
- Preserve the environment by disposing the product in accordance with local, state and federal regulations.

Instructions:


Step 1: Place 3xAA batteries into the control box and note the polarity.

Step 2: Press the button on the control box to select different lit on mode.

Step 3: The built-in timer will light it up for 6 hours after lit mode selected, and then turn off automatically. The light will turn on again after 18 hours unless the Off mode is selected.

Troubleshooting:

If you are experiencing problems getting your LED string light up, try the following suggestions. If problems still persist, please call our customer service number at 800- 933-7188.



Problem	Possible Cause	Corrective Action
LED light will not turn ON.	No battery or wrong polarity.	Place 3 AA batteries and make sure polarity is correct.
	Battery is depleted.	Replace new batteries for all 3 units.
LED light flickers or is getting dimmer.	Battery is low.	Replace new batteries for all 3 units.

Product Warranty & Support Information:

For customer support call 800-933-7188 or visit <http://www.novolinkinc.com/>.

This product comes with a limited warranty of 3 month from the date of purchase. (Proof of the date of purchase must be provided if the product is returned.) If the product is found to be defective in material or workmanship, Novolink will replace the defective part(s). If any of the product parts are found to be missing, please contact Novolink within ten (10) days of purchase.

Thank you for your purchase. We appreciate your business.

NOVOLINK INC.
14790 Yorba Court
Chino, CA 91710