

## CinoArt PT2 - Precision Tamp (Automatic Coffee Tamper)

### User Guide / Setting Main Features



#### Setting Pressures:

- Save Up to 3 Quick Pre-Set Pressures.
- Example: Pre-Set icons 10kg, 20kg or 30kg can be adjusted using the **P** adjustment arrows and then saved by a single push of the (Dn-Up) button.

#### Segmented Multi Tamping:

- Within each Pre-Set Pressure, you can set up to 3 Segmented Tamping Pressures.
- Choose between a single, double, or triple tamp for each Pre-Set Pressure.
- Example: 1st Tamp value set at (e.g.) 8kg followed by the 2nd Tamp at (e.g.) 30kg of pressure or any value combination in between 2kg - 38kg.

#### Setting a Segmented Multi Tamp:

1. Select the Pre-Set Pressure icon you wish to adjust – either 10kg, 20kg or 30kg.
2. At the same time, Press the Up-arrow **T** adjustment button and the (Dn-Up) button.
3. The screen will then show the first (1) tamp pressure which you can adjust using the Increase/Decrease **P** +/- kg adjustment buttons.
4. To save changes press (Dn-Up) button.

#### Cleaning Mode:

- Press and hold (Dn-Up) to entre Cleaning Mode - Tamper Comes Down
- Press and hold (Dn-Up) to entre Cleaning Mode - Tamper Returns Up

#### Sleep Mode:

- Press and hold the Decrease Down-arrow **T** Tamp Adjustment button together with the (Dn-Up) button at the same time.
- The exit Sleep Mode briefly press the (Dn-Up) button to wake up PT2.

Reference: **P** = Pressure Adjustments, **T** = Tamper Cycle Adjustments, **Dn-Up** = Save / Cleaning Mode