

# ELITE EXECUTIVE



## NOW HEAR THIS

The Elite Executive receives every radio wavelength –AM(MW), FM, LW, and Shortwave (SW)–at home or abroad. Plus, it receives VHF aircraft band, Single Sideband (SSB) and includes a PLL tuner so your AM signal is strong and clear.

## RDS READY

The Elite Executive radio features RDS for FM so you can see the station's call letters, style of music, song title, artist and more.

## IN SYNC...AND SENSITIVE

The Executive's Sync Detector improves the radios sound quality by lowering distortion and fading. And it's way sensitive so it can pick up weaker signals.

## LISTEN IN

Want to shut out the world? Just plug in headphones and tune out. Tired of radio? Connect any audio device using the line input and listen to your favorite playlist.

<p><b>am   fm   lw</b> Receives AM/FM/LW Band</p>	 Receives Shortwave Band	 Receives Aircraft Band
<p><b>digital tuning</b> Digital Tuner</p>	 World Time Settings	 Audio Line Input
<p><b>SSB</b> Receives Single Side Band</p>	 Headphone Jack	<p><b>:SD:</b> Sync Detector</p>
<p><b>ATS</b> Automatic Tuning Storage</p>	 Alarm Clock	

# AM/FM/LW/Shortwave Radio with SSB

## TIME KEEPER

The Elite Executive features local and world time settings, radio and buzzer alarm clock settings, sleep timer, and time backup. The bright orange LCD display with backlighting makes it easy to keep time...in any zone.

## GREAT MEMORY

You'll never forget where to tune in thanks to the 700 station memory storage for all frequencies.

## GET POWERED UP

Plug in the AC adapter (included) for full power or use 4 AA batteries (sold separately). The battery strength indicator on the display will let you know when it's time for a change.

## FEATURES

- AM/FM/LW/SW bands
- PLL synthesized dual conversion receiver
- FM with RDS (Radio Data System)
- Local/DX switch
- Single sideband (SSB) with +/1 kHz tuning
- Local/world time zones
- VHF Aircraft band
- Clock/Alarm/Sleep Timer with time backup
- Automatic or Manual Digital Tuning
- Rich orange LCD display
- FM stereo/mono selection
- Reset/Lock button
- Electronic/volume/treble/bass control
- FM telescopic antenna
- Sync detector with selectable sideband
- Power supply: AC adapter or 4 AA batteries (sold separately)
- Direct key-in meter band for SW
- Leather case with craftsman stitching
- 700 memory stations



## SHORTWAVE BANDS

AM	520-1710 kHz (10k)
FM	87.5-108 MHz
LW	150-285 kHz
SW	1.711-30 MHz
AIR	118-136 MHz

## PRODUCT SETUP INFORMATION

Color	Item Number	UPC
Elite Executive	NELITEEXECUTIVE	750254810978
What's included	Product Size & Weight	
Elite Executive	Height: 4.1" (10.5 cm)	
Owner's manual	Width: 6.6" (16.8 cm)	
Micro-USB cable with AC adapter	Depth: 1.2" (3.1 cm)	
	Weight: 15.5 oz (439 g)	
Packaging Dimensions*	Master Carton Dimensions*	
Height: 5.35" (13.59 cm)	Height: 22" (57 cm)	
Width: 10.51" (26.7 cm)	Width: 11" (27.2 cm)	
Depth: 1.93" (4.9 cm)	Depth: 11" (28.8 cm)	
Weight: 30 oz (850 g)	Weight: 39 lbs (17.8 kg)	
Case Quantity	20	

## Meet the Elite Family of Shortwave Radios



Elite Satellit



Elite Field



Elite Executive



Elite Traveler



Elite Mini