



INSTRUCTIONS

**CRYSTAL PALACE
100 YEARS AT SELHURST**


INTRODUCTION

The watch is packed with references to the rich history of Crystal Palace F.C. featuring “South London & proud” and “100 years at Selhurst Park” on the dial as a visual expression of the club.

With the pulsometer scale you will be able to measure your heart rate, while the stainless steel caseback and crown features the Crystal Palace crest and an embossed logo.

USE YOUR PULSOMETER


Find your pulse. When ready, push button A, count 30 heartbeats, push button A again to stop the chronograph. The secondhand will now tell you how many beats per minute your heart is beating.



SPECIFICATIONS

Caliber:	MIYOTA 6S20 Chronograph (Quartz)
Battery life:	Approx. 3 years SR927W (recommended)
Glass:	Sapphire Crystal
Water Resistance:	10. ATM - Water tested to 100 Meters Suitable for swimming

DISPLAY AND BUTTONS



Go to www.aboutvintage.com for warranty information

HOW TO SET TIME

1. Unscrew the crown counterclockwise and pull out to second click position.
2. Turn the crown clockwise to set hour and minutes hand.
3. Push the crown back into normal position.
4. **Always** securely screw in the crown.
You do so by pushing the crown towards the watch while screwing it clockwise until it's 100% tight.

If this is not done correctly you risk that moist and dust will enter your watch!

USING THE CHRONOGRAPH

This chronograph is able to measure and display time in 1/20 second united up to maximum of 59min 59sec. The chronograph 1/20 second hand keeps continuously for 30 seconds after starting, and then stops at Zero position.

1. Press button " A " to start the chronograph.
2. The chronograph can be started and stopped each time button "A" is pressed.
3. Press button "B" to reset the chronograph and chronograph minute and second hands return to their Zero positions.

CHRONOGRAPH RESET

This procedure should be performed when the chronograph second hand does not return to the Zero position.

1. Pull the crown out to the 2nd Click Position.
2. Press the button "A" once to set the chronograph second hand to the Zero position.
3. Press the button "B" once to set the chronograph 1/20 second hand to the Zero position.
4. Once the hands are set at Zero position, reset the time and return the crown to its normal position.



FOR THE TRUE GENTLEMAN AND WOMAN

We are profoundly grateful.
Thank you for your support.

Take good care of your new timepiece.
Make moments, give it history
- let it become vintage.