

SOUL GEAR SOLAR USB DRY BAG SPEAKER

DISCLAIMER: The performance of these products depends on correct use of the dry bag roll top closure and phone case snap closure. Protect both items from sharp objects during use and always inspect your dry bag and phone pouch before use for wear and tear. We recommend you take the precaution not to place sensitive equipment such as electronics directly into the dry bag without an additional sealed dry sack.

Solar Sporting Goods assumes no responsibility for any incidental or consequential damage to any property used in conjunction with these units and is not responsible for any damage caused to users or to their equipment by use of the SOUL GEAR Dry Bag Speaker or accompanying phone pouch. In no case shall Solar Sporting Goods' liability exceed the original cost of the unit purchased.

1 Year Limited Warranty

This limited warranty is in lieu of all other warranties, expressed or implied, and does not cover consequential damages of any kind that may arise from the use or misuse of Solar Sporting Goods product. Solar Sporting Goods products are guaranteed for materials and workmanship for one year from date of purchase. Normal wear and tear, damage resulting from any misuse, accidents or alterations are not covered by the limited warranty. This warranty is void with commercial use. Solar Sporting Goods will repair or replace this unit at its discretion during the life of this warranty. 2019 Solar Sporting Goods, Rockville, MD 20853 USA

Contact Solar Sporting Goods at warranty@solarsportiggoods.com for a return authorization.

Dimensions after rolling 3-4x

10 Liter	8.5" Dia; 16" high
20 Liter	10" Dia; 18" high

Weight

10 Liter	416 grams
20 Liter	520 grams

500D

**WATERPROOF
MATERIAL**



WARNING: THIS DRY BAG IS NOT A LIFE SAVING DEVICE.
WARNING: Cancer and reproductive harm. For more information, go to www.P65Warnings.ca.gov

SCAN QR CODE
FOR WARRANTY REGISTRATION

SOUL GEAR

Keep the Music!

Solar & USB Charged Bluetooth Speaker & LED Dry Bag
Superbly Constructed for Outdoor Adventures



SOUL GEAR
Solar/USB Powered Dry Bag &
Bluetooth Speaker
Model: SG10 & SG20

User Guide

Before using this product, please turn off the device and fully charge the battery via USB cable for 2 hours. While charging, the red LED indicator light will be on, and after full charge the light will turn off.

CORRECT USE: To close the dry bag, align the top two edges of the dry bag and roll down tightly at least three or more times away from you, then secure the buckle by clipping it toward you. To close the phone pouch, properly align the roll clips and flip the tabs into the closed position securely.

AVOID UNINTENDED BATTERY DRAIN - AFTER DISCONNECTING BLUETOOTH, VERIFY THAT LED LIGHTS ARE ALL OFF PRIOR TO STORAGE. Press the power button several times to cycle through the LED lighting options until all LEDs are off.

1. Reinforced polymer snap lock + handle
2. 2 adjustable backpack carry straps
3. 3Ω / 3 Watts Waterproof (IP66) Speaker
4. Solar Charge 10-12 Hours
5. Micro USB Charge 2 Hours
6. Red LED Indicator
 - a. On during charge
 - b. Off after full charge

NOTICES:

- Do not dispose product into fire
- Do not remove wireless speaker and LED panel from the dry bag
- Do not use the LED lights or speaker while USB charging
- Always charge the device fully before storing the bag for extended periods
- Do not carry sharp objects inside the bag to avoid unforeseen damage

PHONE POUCH

1. IPX 8 – Tested underwater at 30 feet for 1 hour
2. Velcro arm band
3. Quick release lanyard



Specifications

Volume	Model:	SG10 = 10 Liters & SG20 = 20 Liters
Material Composition		500D Coated Tarpaulin PVC; high frequency welding technology
Charging Method		Solar & USB
Wireless Speaker		3Ω / 3 Watts
Bluetooth		4.0
Connection Range		10 M / 32 Feet
LED Type		RGBW
Battery (Built-in)		Lithium Polymer 3.7V, 1000mAh
Solar Panel		5V / 100mA
Waterproof Rating		IP66
Charge Port		Micro USB

Function

Key Features	Dry Bag Backpack with Built-in Wireless Speaker & RGBW LED Light panel
Carry Style	2 Adjustable Shoulder Straps
Charge Time	Solar Charge 10-12 hours under direct sunlight; USB Cable: 2 hours
Charge Indicator	Red Light indicates device is charging; green light indicates Bluetooth is in operation
LED Lights	Music > RGB Color lights dance to the music Soft > RGB Color lights fade in and out Night > White light at normal brightness Bright > White light at extra brightness SOS > Red light flashes per int'l SOS signal
Power Button	Press one second to alter light modes; press and hold 3 seconds to activate Bluetooth
Bluetooth Keyword	eFlatables
PHONE POUCH	CAUTION: Electronic devices may overheat in sealed cases.

IMPORTANT: This dry bag is not intended for full submersion.

Solar Sporting Goods, LLC
www.solarsportinggoods.com
info@solarsportinggoods.com
All Rights Reserved.