

1. Plug all cables into the POE-LINK LED power unit.
2. Turn the volume all the way up on the tablet after all cables have been plugged in.
3. iCON has been preprogrammed with the following list of frequency's.
4. To be used with a frequency tone generating application to operate the LED bars.

<b>Color</b>	<b>Frequency (Hz)</b>	<b>State</b>
Off	100	Solid
High Red	200	Solid
Low Red	300	Solid
High Orange	400	Solid
Low Orange	500	Solid
High Yellow	600	Solid
Low Yellow	700	Solid
High Green	800	Solid
Low Green	900	Solid
High Blue	1000	Solid
Low Blue	1100	Solid
High Purple	1200	Solid
Low Purple	1300	Solid

- The iCON system has been configured to display the chosen colors from the list above when the corresponding color to frequency is generated for a duration of 5 seconds at full volume.
- Although not necessary we do recommend that the frequency be repeated every 10 minutes to continue accuracy of color.
- A change in color may take up to 5 seconds to change when the tone is generated.
- The iCON system has been preprogrammed with the above frequencies and is not programmable by the end user.