Product Data Sheet

Food Safe Wax



Product	Food Safe Wax
Size	200ml, 1L, 2L
Description	Food Safe Wax is a soft, creamy beeswax-based polish designed to nourish timber for food preparation areas. It is also excellent on furniture, in particular, children's furniture.
Used For	Nourishing and protecting timber.
Surface Preparation	Ensure the surface is clean and free of dust before applying.
How to Apply	Apply sparingly with a clean, dry cloth in a circular motion, wiping away any excess with another clean, dry cloth.
Dry Time	20 minutes provided excess is wiped away.
Maintenance	Depending on wear, as surface becomes dull or dry.
Clean Up	Warm, soapy water for hands or cloth. Excess wax on timber; dampen a cloth with citrus solvent.
Safety	 Non toxic. Hang out rags to dry, or soak in water. Don't leave scrunched up. May contain traces of bee pollen & soy Contact Gilly's for SDS
Ingredients	Beeswax, soy wax, carnauba wax, d-limonene, soap flakes and water
Image	Food Safe Wax *Kitchen timber *Chopping boards *Children's toys Clear 200ml

W: www.gillysaustralia.com.auE: orders@gillysaustralia.com.au

Ph: (08) 9295 1973