

Corrupt LCD/UI Fix (Only for P120 V4)

UI Controller Assets Update Process - ui.bin

If UI on LCD panel becomes corrupted, please follow the procedure below to recover:

A blank screen, white or black is not a corrupted display.

A corrupted display will have jumbled or pixelated colored static like areas where the icons should be.

1. Download ui.bin
2. Setup [WiFi](#)
3. Open web browser on computer, input **http://printer_ip_address/up** E.g., **http://192.168.1.104/up**
4. Browse to the location where **ui.bin** was saved to and click "Upload UI". **DO NOT UPLOAD lcd.bin**

