



PANDA PLAYGROUND

INSTRUCTION MANUAL



www.ezplaytoys.com



Please read this page before beginning the assembly process.

Structures are not intended for public use. EZPLAY does not warranty any of its indoor playground subjected to commercial use such as: Daycare, Preschool, Nursery School, Recreational Park, or any similar Commercial Application.

Children must **NOT** use this playground until unit has been completely assembled and inspected by an adult to insure the set has been properly installed and anchored.

Please follow all recommendations below. Failure to do so, may result in the warranty being voided and/or safety violations that may result in serious injury.

LOCATION AND PLACEMENT OF PLAYGROUND

Playground is intended for indoor use only. It is not recommended for outside use and all warranty will be voided if used outside.

TOOLS REQUIRED FOR ASSEMBLY


The following tools are required for assembly, but are not included in the Panda Playground Kit. Assembly will require the use of a rubber mallet.

In addition, an Hex (allen) key size 4 mm will be required for assembly and is included with the playground.


CLEANING PLAY-SET

If playground gets dusty or sticky, wipe down using a wet rag only and dry with a dry-cloth.

Ax1



Bx1



Cx1



Dx1



Ex2



Fx2




Gx2




Hx4




Jx1




Kx1



Lx1



Mx1




Nx3



Px2




Qx6



Rx2




Sx14



Tx1



Wx4




Xx2




Assembly process




1



2




3




Note: Make sure the thread and labyrinth are aligned on the sides of A and B




4



5




6




Note: Make sure the thread and labyrinth are aligned on the sides of C and D


7




8



9




10




11


Note: Please make sure that platform K is installed securely and does not wobble.



12




13




Tie knots at desired height after you lead the ropes through platform (M)

14




Step 1

Step 2



KNOTS: Stoppers (Q) are optional. Please secure the ropes for the swing and gymnastic rings by tying knots once you have the desired height.



NOTE: Rings can be installed either in place of the swing, or on the other end as shown above. The platform would need to be removed in order to use the gymnastic rings.

PLEASE READ:

Our products are handcrafted with love and we stand behind their quality! If you have any questions about this playground or have any damaged pieces, please email us at support@ezplaytoys.com and our satisfaction team will help solve your issues as quickly as possible.



We hope that your family enjoys this playground as much as ours have!

IMPORTANT SAFETY PRECAUTIONS

SAFETY: While an indoor play-set will not be subjected to the same abuse as an outdoor play-set that is exposed to the elements of weather change, etc. through frequent use your play-set will experience the normal wear and tear of any household that is blessed with active children. Always inspect your play-set for safety before playtime. Look for fittings that may have become loose, ensure the screws are tight upon unfolding and securing the stored unit. Also, verify that there are no frayed, damaged, or loose ropes.

TESTING: We have successfully tested our play-sets in various types of scenarios. We have put our units through a lot of abuse throughout our various testing methods, with multiple adults attempting to break each item.

Please note that our controlled environment did NOT include cats sharpening their claws or dogs chewing on the ropes, dogs chewing the wood fittings, or termites attacking a unit that has been stored in garage for a period of time while children became of age to use the play-set.

STOPPER KNOTS: Features such as the swing and ladders on our play-set are secured by overhand stopper knots. In addition to the test of time in backyard swings all over the world, our knots in our play-sets have withstood hundreds of pounds of adult abuse. Like all equipment, your ropes and knots on the play-set will be subjected to normal wear and tear. Always inspect your equipment before use, including the knots and rope fittings. We suggest the use of Ashley's knot. Our rope experts at the climbing gym suggest this knot as a beefed up stopper knot for rescue situations.