

BALANCE BOARD & ROLLER WALL BRACKET

SWIFTYFITNESS.COM

This wall bracket from Swifty Fitness is a slick and simple solution for storing your balance board and roller in the home.

Designed to fit a balance board and a roller with a maximum diameter of 150mm and minimum length 250mm.



Made from FSC Certified birch plywood, in Manchester UK.

ASSEMBLY GUIDE

Please read these instructions carefully. If you have any queries relating to the safe mounting of your wall bracket, do not hesitate to contact us.

TOOLS NEEDED

- Power drill - 7mm drill bit - Cross-head screwdriver

INSTRUCTIONS

- 1) Find a suitable wall (solid brick wall or similar) and position away from any wiring or pipes.
- 2) Place the wall bracket against the wall, using a spirit level as a guide, mark the position of the 3 holes on the wall using a pencil.
- 3) Using a power drill with a 7mm bit, drill 3 holes 50 mm deep
- 4) Insert wall plugs into the holes
- 5) Position the wall bracket, and screw in the screws using a cross-head screwdriver

CONTENTS CHECKLIST






DIAGRAM - SIDE VIEW





Load the balance board wall bracket as shown. Do not use for heavier items.

Scan here to explore fitness routines on our youtube channel or go to www.youtube.com/c/SwiftyScootersTV











