


AMERICAN EQ 40



BACK BAY
AUDIO CO.

QUICK START GUIDE


1 YEAR WARRANTY

Thank you for purchasing the American EQ 40 earbuds!

You are covered by our 1 Year Warranty

Register for your free warranty at:
www.backbayaudio.com/warranty


If you have any issues
(or you just want to say hi!)
please feel free to email:
support@backbayaudio.com



BACK BAY
AUDIO CO.

How to Connect Bluetooth Pairing

1) Make sure that bluetooth is enabled on your phone or computer



Hold the middle button for **3 FULL SECONDS**
red and **blue** lights will flash
(If you do not see red and blue lights, it means you are connected to a different phone or computer)

3) Click “Back Bay AE-40” in your device’s Bluetooth menu
If a PIN code is required, try “0000” or “8888”


After you’ve connected once, your device will recognize your earbuds when you turn them on again!

How to Connect Wired Connection

1) Make sure the earbuds are **OFF**

2) Connect the audio connector cable to the earbuds and your device

If you hear any distortion, double-check that **the control box is turned off** by holding the middle button



How to Switch Sound Modes

Switch EQ modes by double-pressing the middle button on the control box. You will hear a beep when the EQ changes.

The earbuds start in mode #1 when you pair to a new phone. To reset to mode #1, select “forget this device” in your phone’s bluetooth settings.


1	Back Bay Signature	The classic American Hi-Fi sound. Strong bass, natural vocals, and crisp highs.
2	Atlanta Bass	Booming bass that will take any rap or EDM track to the next level.
3	Stadium Rock	Tighter and punchier, this setting captures that great 80’s concert sound.
4	Pure Podcast	Loud and clear vocals with the harsh and boomy noise stripped out.
5	Clean Classical	Open and airy clarity with a rich, full tone.

Cable Management

If you like to run with your earbuds, try the shirt clips and cable adjuster to prevent the cable from bouncing


2 Shirt Collar Clips

Attach the clips to the cable and to your shirt collar



Cable Adjuster


Slide to shorten the cable



Finding a Perfect Fit

GREAT FIT = GREAT SOUND


Creating a perfect seal in your ear is extremely important for getting the best sound quality. Try different sizes and styles of ear-tips until you reach the fit and sound that you like.




A LARGER EARBUD TIP WILL GIVE YOU MORE BASS RESPONSE

Stabilizers

Push the ear-tip into your ear canal


Tuck the stabilizer under the fold  in your ear




Charging






Plug the USB charging cable into the charging port




Red light – charging
Blue light – fully charged




Controls



Short Press
 Volume Up
 Volume Down
 Pause Song
 Answer Call
 Hang Up

Long Press
 Next Song
 Previous Song
 Reject Phone Call

Double Press
 Switch sound modes

Please read this user manual carefully before using the earbuds. Please also read your device’s user manual regarding Bluetooth functions. Pay attention to important safety and maintenance information. Please keep the headset away from children.

Specifications

Bluetooth Specification Bluetooth Profiles Supported Audio Decoding Formats Operation Range Frequency Range Battery (Built In)	V4.1 HSP, HFP, A2DP, AVRCP SBC, MP3, APTX Up to 30 Feet 20 Hz – 20,000 Hz Rechargeable 3.7V/ 110mAh Lithium Polymer Battery DC5V
Charging Voltage Charging time Playtime* Talk time*	About 2 Hours Up to 6.5 hours Up to 6.5 hours

*The times mentioned above may vary due to user operation and device settings.