

FIRST CLASS 50

BACK BAY

AUDIO CO.

QUICK START GUIDE

1 YEAR WARRANTY

Thank you for purchasing the First Class 50 earbuds!

You are covered by our 1 Year Warranty

Register for your free warranty at:  
[www.backbayaudio.com/warranty](http://www.backbayaudio.com/warranty)


If you have any issues (or you just want to say hi!) please feel free to email:  
[support@backbayaudio.com](mailto:support@backbayaudio.com)

BACK BAY

AUDIO CO.

Finding the Perfect Fit

Larger Tip = Better Noise Cancelling



Choose the largest tip that fits your ear

Creating a perfect seal in your ear is extremely important for getting the best sound quality and the best active noise cancellation. Try different sizes of ear-tips until you reach the fit and sound that you like.

How to Connect

1) Make sure that bluetooth is enabled on your phone or computer

2)

0:06

Hold the middle button for 6 FULL SECONDS

red and blue lights will flash


3) Click “Back Bay FC-50” in your device’s Bluetooth menu

If a PIN code is required, try “0000” or “8888”

After you’ve connected once, your device will recognize your earbuds when you turn them on again!

Active Noise Cancelling

Double press the middle button on the control box to toggle noise cancelling on and off



You will see an orange light on the control box when noise cancelling in on


The noise cancelling works best for:

- Airplanes
- Trains
- Traffic Noise

Turn on music to cancel out voices

How to Switch Sound Modes

Switch EQ sound modes by holding both volume buttons on the control box at the same time. The headphones will say the name of the new EQ mode




The earbuds start in mode #1 every time you turn them on

1	Back Bay Signature	The classic American Hi-Fi sound. Strong bass, natural vocals, and crisp highs.
2	Atlanta Bass	Booming bass that will take any rap or EDM track to the next level.
3	Stadium Rock	Tighter and punchier, this setting captures that great 80’s concert sound.
4	Pure Podcast	Loud and clear vocals with the harsh and boomy noise stripped out.
5	Clean Classical	Open and airy clarity with a rich, full tone.

Stabilizers

Push the ear-tip into your ear canal


Tuck the stabilizer under the fold A in your ear



Charging


Plug the USB charging cable into the charging port

Red light – charging  
Blue light – fully charged




Neck Band

Place the neck band behind your neck when using the earphones



Controls



Short Press

⏮

 Volume Up

⏭

 Volume Down

⏸

 Pause Song

☎

 Answer Call

⏹

 Hang Up

Long Press

⏮

 Next Song

⏭

 Previous Song

☎

 Reject Phone Call

⏮ ⏭

 Change EQ Mode

Double Press

🔊

 Noise Cancelling On/Off

Please read this user manual carefully before using the earbuds. Please also read your device’s user manual regarding Bluetooth functions. Pay attention to important safety and maintenance information. Please keep the headset away from children.

Specifications

Bluetooth Specification Bluetooth Profiles Supported Audio Decoding Formats Operation Range Frequency Range Battery (Built In)	V4.1 HSP, HFP, A2DP, AVRCP SBC, MP3, APTX Up to 30 Feet 20 Hz – 20,000 Hz Rechargeable 3.7V/ 110mAh Lithium Polymer Battery DC5V
Charging Voltage Charging Time Playtime* Talk Time*	About 2 Hours Up to 6.5 hours Up to 6.5 hours

\*The times mentioned above may vary due to user operation and device settings.