
1. WHAT'S IN THE BOX & THE BASICS

TABLE OF CONTENTS

- 1. WHAT'S IN THE BOX & THE BASICS
- 2. MOUNTING
- 3. MOUNTING YOUR CAMERA WITH THE HELP OF THE MARKS
- 4. ADJUSTING TENSION OF YOUR STANDONE


- 1. Allen keys
- 2. 1/4"-20 Mounting screw
- 3. 1/4"-20 to 3/8"-16 adapter screw
- 4. Foldable legs
- 5. 1/4"-20 Mounting port
- Silicon feet

2. MOUNTING




Mount the tripod head/camera over StandONE by rotating it clock-wise. If you are using a tripod head with a 3/8"-16 mounting port, you will need to attach the included adapter screw(1).

3. MOUNTING YOUR CAMERA WITH THE HELP OF THE MARKS



4. ADJUSTING TENSION OF YOUR STANDONE



You can adjust the tension of the system with the help of a 3mm allen wrench (1). Simply tighten or loosen the screws as shown above.

DISCLAIMER

edelkrone cannot be held responsible for damage caused by improper use or modification of the product.



Before operating your edelkrone, please watch the user's manual video.

http://edel.kr/standone



