

































Feature operation

AutoDial			
Store	AutoDial		▶ AutoDial
Use		AutoDial	
Display	Display	AutoDial	
Call Forward			
Activate	Fwd		▶ Fwd
Deactivate	▶ Fwd		
Reinstate	Fwd	▶ Fwd	
View number	Display	▶ Fwd	
Call Pickup			
		Pickup	
Call Waiting			
Answer		▶ CWT	
Return to first call			
Conference			
	Conf		▶ Conf
Handsfree			
Activate			
Switch to handset			
Handset to handsfree			
Hold			
Place a call on hold			
Return to a held call			
Last Number Redial			
			
Message			
			
Ring Again			
Activate	RngAgn		
When notified		▶ RngAgn	
Deactivate	▶ RngAgn		
Shift			
			
Transfer			
	Trans		▶ Trans

Legend

Icon	Action
()	Indicates the key cap text label. For example, (Message).
	Lift the handset, press the DN key, or press the Handset key.

	Replace the handset, or press  to end the call.
	Dial a number.
	Press the line (DN) key.
▶ AutoDial	The ▶ flashes when a feature is being programmed. The ▶ lights steadily when a feature is active.
	Press the Services key.
	Press the Message key.
	Press the Navigation keys.
	Press the Handsfree key.
	Press the Mute (on/off) key.
	Press the Directory key.

Service and Telephone Options menu











Services menu




Note: The **Services** menu contains the **Telephone Options**, **Password Admin**, **Virtual Office**, and **MG 1000B** menus. These options are not available on all Nortel IP Phone 2004 phones. Consult your system administrator.

Telephone Options menu


Volume adjustment

Ringer	Select		Select	
Handset	Select		Select	
Handsfree	Select		Select	
Headset	Select		Select	
Buzzer	Select		Select	


Contrast adjustment




Language



Date/Time format




Local DialPad Tone



Ring type




OnHook Default Path



Note: The **Directory** key provides access to Corporate Directory, Personal Directory, Redial List, and Callers List. For additional information about your IP Phone 2004, consult the *Nortel IP Phone 2004 User Guide*.

Nortel IP Phone 2004



IP Phone 2004

For Nortel Communication Server 1000

Quick Reference Card

