# ShoreTel 530/560 IP Phone Quick Reference

#### **PHONE OPERATION**

#### Place Calls Off and On Hook

Use the Speakerphone or a Headset

Use the Directory

Make a Conference Call

Use the Intercom

Redial and Check Missed Calls

Dial Paging Extension

#### **Answer Calls**

Send a Call to Voice Mail

Divert a Call

Select a Ring Tone

Adjust the Volume

Answer Call Waiting

Pick Up the Night Bell

#### Interact with Calls

Mute a Call

Place a Call On or Off Hold

Transfer a Call

Join Calls

Park Calls

Unpark Calls

Silently Monitor


Barge In


Change Call Handling Mode

## **Change Extension Assignment**

**Unassign Extension and Go Home** 

Log In and Out of Workgroups






Toggle the Hunt Group Status


Adjust the Display Contrast

# VOICE MAIL Log Into Main Menu Log In from Another Extension

#### **TROUBLESHOOTING**

View Phone Information Reboot Your Phone








# ShoreTel 530/560 IP Phone Quick Reference


#### **LCD Display** Indicator LED Handset with 160 x 80 pixel, 2-bit grayscale Flashing light alerts the Finger Rest user to incoming calls and unheard voice Speaker Scroll Button Soft Keys messages. Delivers Context-sensitive, Select options high-quality in interface. functions defined wideband on display. **Custom Keys** sound. Can be configured as call keys, monitored extensions, or speed ShoreTel 560 Six custom keys with tri-color LED indicators. ShoreTel 530 1 2 3 **Function Keys** 4 5 6 Confessor 7 8 9 Directory Infractor Overlay 1 🛚 🖅 Vinyl overlay imprinted with P P Redai Hold international symbols. **Dial Pad** Headset jack **Audio Control Keys** Volume button controls handset. speaker, and ring volume. Mute, Speaker, Microphone and Headset kevs illuminated when **Function Keys** functions are active. Perform core telephony functions (Voice Mail, Transfer, Options, Conference, Directory, Intercom. Redial, Hold) Note: You can connect a supported headset into the 530/560 IP Phone by plugging the headset into the headset jack at the left corner of the phone chassis. Contact your system

# **GUIDE TO STATUS ICONS**

#### ShoreTel 560 Interface



### Outgoing call: ShoreTel 530



## **Main Display**

Unheard Voice Messages

Missed Calls

¥ ◀ Logged Into Workgroup

Logged Into Workgroup, In Wrap-Up

Logged Out of Workgroup

# **Custom Keys - Call**

On Hook

Off Hoo

Inactive / Do Not Disturb

Incoming Call (Animated)

On a Call

On a Conference Call

Call On Hold / Parked

Remote Hold

#### **Custom Keys - Monitored Extension**

Idle

Inactive / Do Not Disturb

**Unheard Voice Messages** 

Do Not Disturb / Unheard Messages

Incoming Call (Animated)

On a Call

Incoming Call and On a Call

On a Conference Call

Call On Hold / Parked

# **Custom Keys - Speed Dial**

Speed Dial Extension



administrator for details.