


EN

Please take a few minutes to read the instructions before using the product. Please charge and clean the product before using it. It's recommended to use the original charging cable only.

• Product Specifications


Product Materials	ABS, Liquid Silicone
Battery	Li-Ion Rechargeable
Using Time	1 Hour
Charging Time	3 Hours
Waterproof	IPX6
Net Weight	0.79 lbs
Size	10.24*1.57*1.65 in

• Size



EN

• Buttons Display



• Instruction

- Press and hold the button for 3s to turn on/off the device.
- After turning on the device, press the button to switch between 3 thrusting or rotation patterns, and long press to turn off the current mode.
- After turning on the device, press the button (red light on) to warm up the device, and long press to turn off the heating function, or wait for 5 minutes to automatically turn it off.
- After turning on the device, press the button to switch between 10 vibration modes, and long press to turn off the current mode.

EN

• Light Indicator

Charging — Light flashes
Fully charged — Light on permanently
While working — Light on

• Maintenance

- Wash it thoroughly with mild soap and clean water.
- Air dry or dry it with a clean towel.
- Store it in a cool, dry and dust-free place, avoid direct sunlight.

• Attention

- This product is for adult use only; keep out of reach of children.
- It's recommended to use with water-based lubricants.
- Please stop using immediately if you feel uncomfortable during use.


ES

Tómese unos minutos para leer las instrucciones de este manual antes de usar el producto. Por favor, cargue y limpie el producto antes de usarlo. Se recomienda usar solo el cable original.

• Especificaciones del producto


Materiales del producto	ABS, Silicona Líquida
Batería	Li-Ion recargable
Tiempo de uso	1 Hora
Tiempo de carga	3 Horas
Impermeable	IPX6
Peso neto	0.79 lbs
Tamaño	10.24*1.57*1.65 in

• Tamaño



ES

• Visualización de botones



• Instrucciones

- Mantenga presionado el botón durante 3 segundos para encender/apagar el dispositivo.
- Después de encender el dispositivo, presione el botón para cambiar entre 3 patrones de empuje o rotación y mantenga presionado para apagar el modo actual.
- Después de encender el dispositivo, presione el botón (luz roja encendida) para calentar el dispositivo y mantenga presionado para apagar la función de calentamiento, o espere 5 minutos para apagarlo automáticamente.
- Después de encender el dispositivo, presione el botón para cambiar entre 10 modos de vibración y mantenga presionado para apagar el modo actual.

ES

• Indicadores de luz


Cargando — Destellos de luz
Carga completa — Luz encendida Permanentemente
Mientras trabaja — Luz encendida

• Mantenimiento

- Lavar bien con jabón suave y agua limpia.
- Secar con una toalla limpia.
- Guardar en un lugar fresco, seco y libre de polvo, evitar la luz solar directa.

• Atención

- Este producto es solo para uso de personas adultas; manténgalo fuera del alcance de los niños.
- Se recomienda usar con lubricantes a base de agua.
- Por favor, deje de usar inmediatamente si siente algún tipo de incomodidad durante su uso.





EN

Dear Valued Customer,

Thank you for choosing Honey Play Box! We are dedicated to bringing you Intelligent, Sleek, Luxury and Elegant Lifestyle products! Once you registered on our website, you will get the latest updates of our innovative products with creative ways of playing. Enjoy the amazing pleasure!

Honey Play Box Customer Service

BY REGISTERING YOUR PRODUCT ONLINE, YOU WILL VALIDATE YOUR 1-YEAR WARRANTY

Official Website Instagram

FOR LATEST UPDATES, FOLLOW US!

@Honey Play Box

PROVIDING 10 YEARS OF QUALITY SERVICE AND SEXUAL WELLNESS PRODUCTS
<https://www.honeyplaybox.com>

EN

Quality


Surpassing standards from Europe and America

Material Safety

All Honey Play Box products are manufactured using environmental friendly materials including Silicone and ABS plastics. They are harmless to human body.

International Certification

Honey Play Box products have passed EU ROHS certification and meet EU CE Directive and WEEE Directive. Honey Play Box products are "Green" meeting the official safety and environmental protection standard issued by agencies in Europe and North America.



Additional Information:

The EU CE Directive and the WEEE Directive are referred to as the "Twin Directives for Environmental Protection" or "Double Green Directives" and are used to restrict hazardous substances in electronic products including lead, cadmium, and mercury. ROHS stands for "Restriction of the Use of Certain Hazardous Substances"; and WEEE stands for "Waste Electrical and Electronic Equipment". Products that meet the standards set out in these two directives can be advertised as "Green Products".

EU CE Directive:

Is the collective name of a series of product standards issued by the European Union; enterprises complying with the standard may apply for CE certification mark on their products and labelling. Honey Play Box products surpass the standards set out by these directives and are authorized to use the mark identifying that the products comply with all EU requirements.

EN

WARNING!

Proper maintenance and care may extend the product's service life. Before using the product, please read the following safety instruction carefully.

- Please comply with the following before using the product: Clean the product completely. Scrub it with an antibacterial soap and then wash with clean hot water; at last, wipe it gently with towel or soft cloth.
- During using the product
 - NO using massage oil or hand cream as lubricant.
 - NO using silicon-based lubricant, because it'll damage the organosilicone surface.

Reminder: Do not use any cleaning agent containing alcohol, gasoline or acetone to wipe the product. Avoid direct solar radiation and long-time exposure to the high-temperature environment. The product shall be stored in a clean and dry place without contact with other plastic products.

Maintenance of the Built-in Battery:

- This product uses rechargeable batteries. A new battery could play its full effectiveness after two or three charging and discharging processes.
- A battery can be charged or discharged for over 100 times and will go matured finally. After being charged fully, the battery shall be disconnected with the charger, or overcharge may reduce the battery life.
- When the product is idle, the electric quantity of fully charged battery will lose gradually.
- If the product is placed in a too hot or cold place, it will reduce the battery capacity and shorten the battery life. If the battery is too hot or cold, the battery life will be also short even though it is charged fully.

Battery Warning!

- When the battery damaged or tampered with, it could cause fire or chemical burn. Explosion may happen when the battery is damaged.
- The battery shall be disposed in accordance with the local laws and regulations. If possible, please recycle it. Users shall not take out or replace the battery by themselves; otherwise, the risky operation may damage the product.


PT

Reserve alguns minutos para ler as instruções antes de usar o produto. Por favor, carregue e limpe o produto antes de usá-lo. Recomenda-se usar apenas o cabo de carregamento original.

• Especificações do produto


Materiais do produto	ABS, Silicone Líquido
Bateria	Li-Ion recarregável
Usando o tempo	1 Hora
Tempo de carregamento	3 Horas
A prova d'água	IPX6
Peso líquido	0.79 lbs
Tamanho	10.24*1.57*1.65 in

• Tamanho



PT

• Exibição de botões



• Instrução

- Pressione e segure o botão por 3s para ligar/desligar o dispositivo.
- Depois de ligar o dispositivo, pressione o botão para alternar entre 3 padrões de impulso ou rotação e pressione e segure para desligar o modo atual.
- Depois de ligar o dispositivo, pressione o botão (luz vermelha acesa) para aquecer o dispositivo e pressione e segure para desligar a função de aquecimento ou aguarde 5 minutos para desligá-lo automaticamente.
- Depois de ligar o dispositivo, pressione o botão para alternar entre 10 modos de vibração e pressione e segure para desligar o modo atual.

PT

• Indicador de luz

Carregando — A luz pisca
Totalmente carregado — Luz acesa permanentemente
Enquanto trabalha — Luz acesa

• Manutenção

- Lave bem com sabão neutro e água limpa.
- Seque-o com uma toalha limpa.
- Armazene-o em local fresco, seco e livre de poeira, evite a luz solar direta.

• Atenção

- Este produto é apenas para uso adulto; Mantenha fora do alcance de crianças.
- Recomenda-se o uso com lubrificantes à base de água.
- Por favor, pare de usar imediatamente se você se sentir desconfortável durante o uso.