


User Manual




Please take a few minutes to read the instructions before using the product. Please charge and clean the product before using it. It's recommended to use the original charging cable only.

• Product Specifications

Product Materials	ABS, Silicone
Battery	Li-ion Rechargeable
Using Time	1 Hour
Charging Time	2 Hours
Waterproof	IPX6
Net Weight	0.64 lbs
Size	6.42*2.55 in/16.3*6.47 cm

• Size



• Buttons Display



⌚ On/Off & Modes Switching Button

- Magnetic Charging Connection

• Instruction

Controlled with button on vibrator:

- Press and hold the ⌚ button for 2s to turn on/off the device and the heating mode, and press again to switch between 9 vibrating patterns.

• Light Indicator

Charging — Light flashes
Fully charged — Light on permanently
While working — Light on

• Maintenance

- Wash it thoroughly with mild soap and clean water.
- Air dry or dry it with a clean towel.
- Store it in a cool, dry and dust-free place, avoid direct sunlight.

• Attention

- This product is for adult use only; keep out of reach of children.
- It's recommended to use with water-based lubricants.
- Please stop using immediately if you feel uncomfortable during use.