


HONEY
PLAY BOX

User Manual



Pomi Wand


EN

Please take a few minutes to read the instructions before using the product.
Please charge and clean the product before using it. It's recommended to use the original charging cable only.

• **Product Specifications**

Product Name	Pomi Wand
Product Materials	ABS, Silicone
Battery	Li-Ion Rechargeable
Using Time	1 Hour
Charging Time	2 Hours
Waterproof	IPX6
Net Weight	158 g
Size	176*47*47mm


• **Size**



1.85 in (47 mm)
6.92 in (176 mm)



EN

• **Buttons Display**



On / Off & Modes Switching Button
Magnetic Charging Connection

• **Instruction**

- Press and hold the  button for 1.5s to turn on/off the device, device on, light on; device off, light off.
- Press the  button again to switch 10 vibrating patterns.

• **Light Indicator**

charging	light flashes
fully charged	light on permanently
while working	light on permanently

EN

• **Maintenance**

- Before/After usage, wash it thoroughly with mild soap and clean water.
- Air dry or dry it with a clean towel.
- Store it in a cool dry and dust-free place, avoid direct sunlight.

• **Attention**

- This product is for adult use only; keep out of reach of children.
- To avoid any causation of injury, please do not use excessive force.
- Please stop using immediately if you feel uncomfortable while using.
- Do not use this product interchangeably with other people.
- Regular inspection of product is necessary before usage, and stop using when any damage is found.


ES

Tómese unos minutos para leer las instrucciones de este manual antes de usar el producto. Por favor, cargue y limpie el producto antes de usarlo. Se recomienda usar solo el cable original.

• **Especificaciones del producto**

Nombre del producto	Pomi Wand
Materiales del producto	ABS, Silicona
Batería	Li-Ion recargable
Tiempo de uso	1 hora
Tiempo de carga	2 horas
Impermeable	IPX6
Peso neto	158 g
Tamaño	176*47*47mm


• **Tamaño**



1.85 in (47 mm)
6.92 in (176 mm)


ES

• **Visualización de botones**



Botón de On/Off y cambio de modos
Conexión de carga magnética

• **Instrucciones**

- Mantenga presionado el botón  durante 1.5 s para encender/apagar el dispositivo, dispositivo encendido, luz encendida; dispositivo apagado, luz apagada
- Presione nuevamente para cambiar entre 10 patrones de vibración.

• **Indicadores de luz**

Cargando	destellos de luz.
Carga completa	luz encendida permanentemente.
Mientras trabaja	luz encendida permanentemente.

ES

• **Mantenimiento**

- Antes/después del uso, lávelo bien con jabón suave y agua limpia.
- Séquelo al aire o séquelo con una toalla limpia.
- Guardar en un lugar fresco, seco y libre de polvo, evitar la luz solar directa.

• **Atención**

- Este producto es solo para uso de adultos; mantener fuera del alcance de los niños.
- Para evitar cualquier causa de lesión, no use fuerza excesiva.
- Deje de usarlo inmediatamente si se siente incómodo mientras lo usa.
- No utilice este producto indistintamente con otras personas.
- Es necesaria una inspección regular del producto antes de su uso y dejar de usarlo cuando se encuentre algún daño.

HONEY
PLAY BOX

EN

Dear Valued Customer,

Thank you for choosing Honey Play Box! We are dedicated to bringing you Intelligent, Sleek, Luxury and Elegant Lifestyle products! Once you registered on our website, you will get the latest updates of our innovative products with creative ways of playing. Enjoy the amazing pleasure!

Honey Play Box Customer Service

1 Year BY REGISTERING YOUR PRODUCT ONLINE, YOU WILL VALIDATE YOUR 1-YEAR WARRANTY



Official Website



Instagram

FOR LATEST UPDATES, FOLLOW US!

@Honey Play Box

10 Year PROVIDING 10 YEARS OF QUALITY SERVICE AND SEXUAL WELLNESS PRODUCTS
https://www.honeyplaybox.com

EN

Quality


Surpassing standards from Europe and America

Material Safety

All Honey Play Box products are manufactured using environmental friendly materials including Silicone and ABS plastics. They are harmless to human body.

International Certification

Honey Play Box products have passed EU ROHS certification and meet EU CE Directive and WEEE Directive. Honey Play Box products are "Green" meeting the official safety and environmental protection standard issued by agencies in Europe and North America.



Additional Information:

The EU CE Directive and the WEEE Directive are referred to as the "Twin Directives for Environmental Protection" or "Double Green Directives" and are used to restrict hazardous substances in electronic products including lead, cadmium, and mercury. ROHS stands for "Restriction of the Use of Certain Hazardous Substances"; and WEEE stands for "Waste Electrical and Electronic Equipment". Products that meet the standards set out in these two directives can be advertised as "Green Products".

EU CE Directive:

Is the collective name of a series of product standards issued by the European Union; enterprises complying with the standard may apply for CE certification mark on their products and labelling. Honey Play Box products surpass the standards set out by these directives and are authorized to use the mark identifying that the products comply with all EU requirements.

EN

WARNING!

Proper maintenance and care may extend the product's service life. Before using the product, please read the following safety instruction carefully.

- Please comply with the following before using the product: Clean the product completely. Scrub it with an antibacterial soap and then wash with clean hot water; at last, wipe it gently with towel or soft cloth.
- During using the product
 - NO using massage oil or hand cream as lubricant.
 - NO using silicon-based lubricant, because it'll damage the organosilicone surface.

Reminder: Do not use any cleaning agent containing alcohol, gasoline or acetone to wipe the product. Avoid direct solar radiation and long-time exposure to the high-temperature environment. The product shall be stored in a clean and dry place without contact with other plastic products.

Maintenance of the Built-in Battery:

- This product uses rechargeable batteries. A new battery could play its full effectiveness after two or three charging and discharging processes.
- A battery can be charged or discharged for over 100 times and will go matured finally. After being charged fully, the battery shall be disconnected with the charger, or overcharge may reduce the battery life.
- When the product is idle, the electric quantity of fully charged battery will lose gradually.
- If the product is placed in a too hot or cold place, it will reduce the battery capacity and shorten the battery life. If the battery is too hot or cold, the battery life will be also short even though it is charged fully.

Battery Warning!

- When the battery damaged or tampered with, it could cause fire or chemical burn. Explosion may happen when the battery is damaged.
- The battery shall be disposed in accordance with the local laws and regulations. If possible, please recycle it. Users shall not take out or replace the battery by themselves; otherwise, the risky operation may damage the product.

PT

Reserve alguns minutos para ler as instruções antes de usar o produto.
Por favor, carregue e limpe o produto antes de usá-lo. Recomendamos usar apenas o cabo de carregamento original.

• **Especificações do produto**

Nome do produto	Pomi Wand
Materiais do produto	ABS, Silicone
Bateria	Li-Ion recarregável
Usando o tempo	1 hora
Tempo de carregamento	2 horas
À prova d'água	IPX6
Peso líquido	158 g
Tamanho	176*47*47mm


• **Tamanho**



1.85 in (47 mm)
6.92 in (176 mm)


PT

• **Exibição de botões**



Botão de comutação de modos de ligar/desligar
Conexão de carregamento magnético

• **Instrução**

- Pressione e segure o botão  por 1.5s para ligar/desligar o dispositivo, aparelho ligado, luz acesa; dispositivo desligado, luz desligada.
- Pressione novamente para alternar entre 10 padrões de vibração.

• **Indicador de luz**

carregando	a luz pisca
totalmente carregado	luz acesa permanentemente
enquanto trabalha	luz acesa permanentemente

PT

• **Manutenção**

- Antes/Depois o uso, lave-o cuidadosamente com sabão neutro e água limpa.
- Seque ao ar ou seque com uma toalha limpa.
- Armazene-o em local fresco, seco e livre de poeira, evite a luz solar direta.

• **Atenção**

- Este produto é apenas para uso adulto; Mantenha fora do alcance de crianças.
- Para evitar qualquer causa de lesão, por favor, não use força excessiva
- Por favor, pare de usar imediatamente se você se sentir desconfortável durante o uso.
- Não use este produto de forma intercambiável com outras pessoas.
- A inspeção regular do produto é necessária antes do uso e pare de usar quando for encontrado qualquer dano.