


User Manual




Please take a few minutes to read the instructions before using the product. Please charge and clean the product before using it. It's recommended to use the original charging cable only.


• Product Specifications

Product Materials	ABS, Silicone
Battery	Li-ion Rechargeable
Using Time	1 Hour
Charging Time	2 Hours
Waterproof	IPX6
Net Weight	0.64 lbs
Size	Machine: 6.81*2.32 in / 7.3*5.9 cm Dildo: 6.86*1.12 in / 7.4*2.8 cm

• Size



• Buttons Display



• Instruction

Controlled with button on vibrator:

- Press and hold the **⏻** button for 2s to turn on/off the device, and press the **⬠** button to switch between 3 speeds & 2 vibrating modes.
- When the motor is on, press the **⚡** button to activate speedy thrusting pattern lasting for 20 seconds, press again to return back to the original working pattern.

Remote control:

- After the product is turned on by the **⏻** button on the vibrator, press the **F2** button on the remote control to start and switch between 3 speeds & 2 vibrating modes. Long press the **⏻** button to stop vibrating, and press the **F2** button again to restart massaging.

- When the motor is on, press the **F1** button to activate speedy thrusting pattern lasting for 20 seconds, press **F1** again to return back to the original working pattern

• Light Indicator

Charging — Light flashes
Fully charged — Light on permanently
While working — Light on

• Installation Method:

- Align the suction cup connector with the connector at the bottom of the masturbation cup.
- Rotate clockwise
- Rotate to the bottom and lock the positioning fixing ring in the direction of the main engine.

• Maintenance

- Wash it thoroughly with mild soap and clean water.
- Air dry or dry it with a clean towel.
- Store it in a cool, dry and dust-free place, avoid direct sunlight.

• Attention

- This product is for adult use only; keep out of reach of children.
- It's recommended to use with water-based lubricants.
- Please stop using immediately if you feel uncomfortable during use.