User Manual




Please take a few minutes to read the instructions before using the product.Please charge and clean the product before using it. It's recommended to use the original charging cable only.

Product Specifications

| Product Materials | ABS, Silicone |
|-------------------|----------------------------|
| Battery | Li-ion Rechargeable |
| Using Time | 1.5 Hours |
| Charging Time | 1.5 Hours |
| Waterproof | IPX7 |
| Net Weight | 0.12 lb |
| Size | 4.25*2.05 in/10.79*5.20 cm |
| | |

• Size



• Buttons Display



- **Ů** On/Off & Modes Switching Button
- DC Charging Port

Instruction

 Press and hold the U button for 2s to turn on/off the device, and press again to switch between 10 spinning patterns.

• Light Indicator

Charging Light flashes

Fully charged Light on permanently

While working Light on

Maintenance

- Wash it thoroughly with mild soap and clean water.
- Air dry or dry it with a clean towel.
- Store it in a cool, dry and dust-free place, avoid direct sunlight.

Attention

- This product is for adult use only; keep out of reach of children.
- It's recommended to use with water-based lubricants.
- Please stop using immediately if you feel uncomfortable during use.