

Thank you for your purchase! At URSUS we believe that having essential accessories makes a good bike ride great.

⚠ WARNING: CYCLING CAN BE DANGEROUS. BICYCLE PRODUCTS SHOULD BE INSTALLED AND SERVICED BY A PROFESSIONAL MECHANIC. NEVER MODIFY YOUR BICYCLE OR ACCESSORIES. READ AND FOLLOW ALL PRODUCT INSTRUCTIONS AND WARNINGS INCLUDING INFORMATION ON THE MANUFACTURER'S WEBSITE. INSPECT YOUR BICYCLE BEFORE EVERY RIDE. ALWAYS WEAR A HELMET.

For additional product and safety information go to:
www.URSUSCYCLING.com/.

COMPATIBILITY AND INTENDED USE

The HOPPER Two-Leg Kickstand is intended to be installed on bikes used for riding on paved surfaces where the tires maintain contact with the ground.

The HOPPER Two-Leg Kickstand is designed to fit on frames with or without a kickstand plate, and on bikes with 700c or 26" wheels.

NOTE: For frames without a kickstand plate, please consult the frame manufacturer for compatibility. Installation of a kickstand on a frame that is not kickstand-compatible can damage the frame.

TOOLS

- 8mm hex wrench
- 14mm open-end wrench
- Grease

INSTALLATION

1. Clean the frame or kickstand plate of dirt, grease, and other contaminants.
2. Lightly grease threads of fixing bolt.
3. For frames with a kickstand plate: insert 8mm socket-head fixing bolt through split washer and kickstand plate of frame and thread into kickstand. Do not use top plate or hex-head fixing bolt.
4. For frames without kickstand plate: insert hex-head fixing bolt through split washer, top plate, between chainstays, and thread into kickstand. Position kickstand as close to the bottom bracket shell as possible without interfering with cables.

⚠ WARNING: Before fully tightening fixing bolt, ensure neither the kickstand, fixing bolt, nor top plate interfere with derailleur cables.

⚠ WARNING: Over tightening the kickstand on frames without a kickstand plate can damage the frame, rendering it unsafe to ride.

5. Tighten fixing bolt until snug and kickstand can no longer move, or to the frame manufacturer's specification.

ONGOING MAINTENANCE

Periodically inspect your URSUS HOPPER Two-Leg Kickstand to make sure the fixing bolt is tight and the kickstand cannot move.

WARRANTY REGISTRATION

Proof of purchase is required before a warranty claim is processed. URSUS therefore strongly encourages warranty registration. Failure to register will not affect consumer rights, so long as the consumer can show in a reasonable manner proof of original ownership and the date the URSUS HOPPER product was purchased.

If you have any questions visit URSUSCYCLING.COM for more warranty information.