




CARPO-L2

COMPACT POWERED SPEAKER SYSTEM



Sound Town Inc. Accepts no liability for any loss which may be suffered by any person who relies either wholly or in part upon any description, photograph, or statement contained herein. Technical specifications, appearances and other information are subject to change without notice.

For the applicable warranty terms and conditions, including additional information regarding Sound Town's limited warranty, please find details online at:

<https://www.soundtown.com/pages/return-warranty>



Please carefully read the user manual before using our products.
Lea este manual atentamente antes de utilizar nuestros productos.

IMPORTANT SAFETY INSTRUCTIONS

1. Read all safety and operating instructions before using this product.
2. All safety and operating instructions should be kept for future reference.
3. Read and understand all warnings listed on the operating instructions.
4. Follow all operating instructions to operate this product.
5. This product should not be used near water, i.e. Bath tub, sink, swimming pool, web basement etc.
6. Only use dry cloth to clean this product.
7. Do not block any ventilation openings, it should not be placed flat against a wall or placed in a built-in enclosure that will impede the flow of cooling air.
8. Do not install this product near any heat sources, such as, radiators, heat registers, stove or other apparatus (including heat producing amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The side blade or the third prong are provided for your safety if the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord being walked on or pinched particularly at Plugs, convenience receptacles and the point where they exit from the apparatus. Do not break the ground pin of the power supply cord.
11. Only use attachments specified by the manufacturer.
12. Use only the cart, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart is used use caution when moving cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Care should be taken so that objects do not fall and liquids are not spilled into the unit through the ventilation ports or any other openings.
15. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way; such as, power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally or has been dropped.
16. WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
17. When the MAINS plug, or an appliance coupler is used as the disconnect device, the disconnect device should remain readily operable.
18. Protective Ground Terminal: The apparatus shall be connected to an AC main socket with a protective earth ground connection.



FEATURES

- The SOUND TOWN CARPO-L2 compact powered speaker system is designed for quality sound while takes small footprint. The entire system is light enough to be carried in a single trip. The integrated 12" bass enclosure with an intuitive user interface can be easily set up with the column array speaker in a minute.
- It features versatile connections with 2-channel (inputs for microphones, music instruments, line level devices, TWS bluetooth linking and streaming devices) which provide great compatibility with a variety of sound and speaker systems.

In the package

- 1 CARPO powered subwoofer
- 2 Loudspeaker Array
- 1 Extension
- 1 Remote Control
- 1 Power cable
- 1 Carry bag for extensions & array


How can we help you?

CONTACT OUR US-BASED SUPPORT TEAM

Simple or complex, your questions are important to us. For service, support or more information, please contact the Sound Town support team:

Email: support@soundtown.com

REAR PANEL INSTRUCTION



REAR PANEL INSTRUCTION

1. MP3 Player

MODE	Long press to turn on/off the MP3 module; Short press to Interchange between USB/SD/Bluetooth mode
▶ / TWS	Play or Pause / Long press for TWS bluetooth pairing (To pair the other speaker)
🔄	Repeat
⏮	Previous Song / Long press for rewinding
⏭	Next Song / Long press for fast-forwarding

2. **Channel 1 Input:** 1/4" / XLR combo input. (Mic/Line signal switchable)

3. **MIC/LINE Switch:** Switch to select Mic or Line signal for Channel 1.

4. **LEVEL 1:** To adjust the input level of channel 1.

5. **Channel 2 Input:** 1/4" / XLR combo input. (Line signal only)

6. **LEVEL 2:** To adjust the input level of channel 2 or Mp3 player.

7. **Line Output:** XLR signal output. (Mixed out)

8. **MASTER VOLUME:** Adjust the overall volume of the system.

9. **DSP (EQ Preset):** There are 3 different EQ setting (Live/Speech/Music), push this button to select one according to your application.

10. LED Indicator:

LIVE LED: Illuminated when 'LIVE' mode EQ is selected.

SPEECH LED: Illuminated when 'SPEECH' mode EQ is selected.

MUSIC LED: Illuminated when 'MUSIC' mode EQ is selected.

POWER LED: Illuminated when unit is on.

LIMIT LED: Lights up when the amplifier is near clipping. An occasional flickering is acceptable

If LED is lit continuously adjust the level control and reduce the output level of connected sources.

Failure to do so may lead to premature failure of your speaker.

11. **Voltage Selection:** This switch is supplied for moving the unit from 115V (U.S. standard) to 230V (European standard). The switch needs to be set on the proper voltage for your area.

12. **IEC Input:** This receptacle is for connecting the IEC power cable. It's important to supply the proper AC line voltage to the unit. Do not connect to intermittent or faulty power.

13. **Power Switch:** To turn on/off the unit.

BLUETOOTH INSTRUCTIONS

Single speaker Bluetooth Pairing:

1. Turn on the power of the speaker, Press the 'MODE' (Interchange) button on the MP3 panel to launch Bluetooth mode. Screen message ('bt'). The speaker will become discoverable as 'SOUNDTOWN'.
2. In the setting of your Bluetooth enabled devices, set it to 'discover' available devices. From the Bluetooth device list, select the 'SOUNDTOWN' device.
3. The speaker is now paired with your Bluetooth enabled device.

Two speakers Bluetooth Pairing (TWS linking):

The system support 'Ture Wireless Stereo' linking which allows you to connect the other speaker by Bluetooth.

1. Turn on the power of the first speaker (Master speaker).
2. Press 'MODE' button to interchange Bluetooth mode (screen message 'bt')
3. Turn on the power of the second speaker (Slave speaker).
4. Press 'MODE' button (slave speaker) to interchange Bluetooth function (screen message 'bt')
5. Long press the play/pause '▶||' (5 seconds) on the master speaker then you will hear a voice prompt 'right channel' from the master speaker, and 'left channel' from the slave speaker, the two speakers are paired successfully.
6. Connect your Bluetooth audio device to the master speaker and enjoy the 'TRUE WIRELESS STEREO' sound.

Note: At first time TWS pairing, there might have some 'sa sa sa..' noise which is not malfunction.

The two speakers are identical to each other, either one can be used as master or slave speaker.

TECHNICAL INFORMATION


Mechanical

- LF size: 12"
- Subwoofer cabinet size: 14.8" x 19.4" x 20" (W x D x H)
- Subwoofer cabinet weight: 36 Lbs
- Array speaker size: 3" x 4 each. (2 x Array speakers included)
- Array Column size: 3.7" x 3.7" x 18" each (2 x Array speakers included)
- Array Column weight: 4.8 Lbs each (2 x Array speakers included)
- Extension size: 3.7" x 3.7" x 18"
- Shipping Carton Size: 21.5" x 21.5" x 22.1" (W x D x H)
- Shipping Gross Weight: 55 Lbs

Electrical

- AC power rating: 100~240V, 50/60Hz 400W max

REMOTE CONTROL INSTRUCTIONS



1. Short press to play a song or pause while playing a song. Long press for TWS bluetooth pairing. (To pair the other speaker)
2. Press to select between 3 EQ presets LIVE/SPEECH/MUSIC mode.
3. Press '+' for volume up and '-' for volume down.
4. Previous: Short press once to jump to previous song. Long press for rewinding.
5. Next: Short press once to jump to next song. Long press for fast-forwarding.
6. Keys: Use this key to select the number of a desired track.
7. Pick song: Allows you to go directly to a desired song, for example: if you want the song no.11, first press the number 11 then press this button.
8. ENTER: Choose 'Repeat' mode.
9. MODE: Press to interchange between SD/USB/BLUETOOTH.
10. Battery compartment.