

TMP100

Setup

1 Set the TMP100 on a flat surface or use one of the several mounting holes at its bottom to mount it onto a tripod.

2 Extend the tray to place your tablet/phone on it.



3 Release the screen by pulling on the upper pins on both sides.



4 Rotate the screen to set it at a 45-degree angle.

5 Use the bottom pin on each side to lock the screen into position.



6 Mount the camera onto the back plate.

7 Cover lens with the black cloth attached to the screen.

8 Adjust the position of the camera so its lens is as close as possible to the screen.

TMP100

9 Install a teleprompter application on your cell phone or tablet.

WARNING: Please note that the application must allow mirroring of text to be used with the TMP100.

WARNING: The TMP100 does not come with an application for cell phone or tablet.

10 Type the speech in the application. Set the speed for the scrolling of the text.

11 Mirror the text in the application.

12 Place the tablet or cell phone on the tray of the TMP100.



13 Lock the tray in position using the 2 thumb screws below the camera platform.