




GoControl LED 60-watt Light Bulb



Pairing with your Constellation Connect Hub

1. Enter the device wizard on your mobile app or online account
2. Select GoControl LED 60-watt Light Bulb from the list of available devices
3. Follow the in app or online account instructions to begin the pairing process with the Constellation Connect Hub
4. Turn off the power to the selected lighting device to be used with the GoControl LED bulb
5. Screw the GoControl LED Light Bulb into the lamp socket
6. Turn the selected lighting device back on
7. The GoControl LED Light Bulb will flash twice as a confirmation that the pairing process is complete with your hub
8. Your GoControl LED 60-watt Light Bulb is successfully connected to your Constellation Connect Hub and will appear as a device in the device list
9. (Optional) Follow the on-screen instructions to name your GoControl Light Bulb and assign it to a room.

Basic Operation

Note: The GoControl LED 60-watt Light Bulb can be controlled ON/OFF/BRIGHT/DIM through your app or online account

1. To manually turn the GoControl LED Light Bulb ON: Flip the wall switch to on
2. To manually turn the GoControl LED Light Bulb OFF: Flip the wall switch to off

For additional information, please contact us

Constellation Connect Support | 1.888.918.7128 | support@constellationconnect.com | constellationconnect.com/contact