



Owner's manual

Rize Home Smart Duvet





Table of contents

Safety and precautions	4
Parts list	7
Installation guide	8
Washing guide	14

Safety and precautions

- 1) IT IS IMPORTANT TO READ ALL THE INSTRUCTIONS BEFORE USING THIS DEVICE. ONLY USE THIS DEVICE SUCH AS DESCRIBED IN THE MANUAL. PLEASE PROTECT YOURSELF AND PROTECT OTHERS AROUND YOU BY FOLLOWING THOROUGHLY ALL THE SECURITY INFORMATION AS DESCRIBED IN THIS INSTRUCTION MANUAL. ANY USE NOT RECOMMENDED BY THE MANUFACTURER CAN CAUSE AFIRE, ELECTROCUTION, DAMAGE TO YOUR PROPERTY OR CORPORAL INJURIES.
- 2) EXTREME CAUTION IS NECESSARY WHEN ANY HEATER IS USED BY OR NEAR CHILDREN OR INVALIDS AND WHENEVER THE HEATER IS LEFT OPERATING AND UNATTENDED.
- 3) ALWAYS UNPLUG HEATER WHEN NOT IN USE.
- 4) DO NOT OPERATE ANY HEATER WITH A DAMAGED CORD OR PLUG OR AFTER THE HEATER MALFUNCTIONS, HAS BEEN DROPPED OR DAMAGED IN ANY MANNER. DISCARD HEATER, OR RETURN TO AUTHORIZED SERVICE FACILITY FOR EXAMINATION AND/OR REPAIR.
- 5) WARNING: TO REDUCE THE RISK OF FIRE, KEEP CURTAINS, OR ANY OTHER FLAMMABLE MATERIAL A MINIMUM DISTANCE OF 1 M FROM THE AIR OUTLET.
- 6) WARNING: DO NOT USE THIS HEATER IN SMALL ROOMS WHEN THEY ARE OCCUPIED BY PERSONS NOT CAPABLE OF LEAVING THE ROOM ON THEIR OWN, UNLESS CONSTANT SUPERVISION IS PROVIDED.
- 7) DO NOT USE OUTDOORS.
- 8) THIS HEATER IS NOT INTENDED FOR USE IN BATHROOMS, LAUNDRY AREAS AND SIMILAR INDOOR LOCATIONS. NEVER LOCATE HEATER WHERE IT MAY FALL INTO A BATHTUB OR OTHER WATER CONTAINER.
- 9) DO NOT RUN CORD UNDER CARPETING. DO NOT COVER CORD WITH THROW RUGS, RUNNERS, OR SIMILAR COVERINGS. DO NOT ROUTE CORD UNDER FURNITURE OR APPLIANCES. ARRANGE CORD AWAY FROM TRAFFIC AREA AND WHERE IT WILL NOT BE TRIPPED OVER.

Safety and precautions

- 10) TO DISCONNECT HEATER, TURN CONTROLS TO OFF, THEN REMOVE PLUG FROM OUTLET.
- 11) CONNECT TO PROPERLY GROUNDED OUTLETS ONLY.
- 12) DO NOT INSERT OR ALLOW FOREIGN OBJECTS TO ENTER ANY VENTILATION OR EXHAUST OPENING AS THIS MAY CAUSE AN ELECTRIC SHOCK OR FIRE, OR DAMAGE THE HEATER.
- 13) TO PREVENT A POSSIBLE FIRE, DO NOT BLOCK AIR INTAKES OR EXHAUST IN ANY MANNER.
- 14) A HEATER HAS HOT PARTS INSIDE. DO NOT USE IT IN AREAS WHERE GASOLINE, PAINT, OR FLAMMABLE LIQUIDS ARE USED OR STORED.
- 15) USE THIS HEATER ONLY AS DESCRIBED IN THIS MANUAL. ANY OTHER USE NOT RECOMMENDED BY THE MANUFACTURER MAY CAUSE FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS.
- 16) ALWAYS PLUG HEATERS DIRECTLY INTO A WALL OUTLET/RECEPTACLE. NEVER USE WITH AN EXTENSION CORD OR RELOCATABLE POWER TAP (OUTLET/POWER STRIP).

SAVE THESE INSTRUCTIONS. Proper operation of your duvet is necessary to ensure the long life and durability you expect from a high-quality product. The manufacturer has tested and inspected this product prior to shipment.

Safety and precautions

DO NOT PLACE BODY PARTS DIRECTLY IN OR IN FRONT OF THE AIR NOZZLE'S EXHAUST WHEN IT IS USED AT A HIGH TEMPERATURE.

DO NOT USE THE SMARTDUVET WITH A BABY, A DISABLED PERSON, A PERSON WITH DIMINISHED CAPACITIES OR ANY PERSON SENSITIVE TO HEAT, SUCH AS SOMEONE WITH BAD BLOOD CIRCULATION.

DO NOT USE THE SMARTDUVET WITH CHILDREN OR WITH PEOPLE HAVING MENTAL OR SENSORIAL HANDICAPS.

DO NOT OPERATE WITH A DAMAGED CORD OR PLUG OR AFTER A MALFUNCTION, OR IF THE UNIT HAS BEEN DROPPED OR DAMAGED IN ANY MANNER. DISCARD OR RETURN TO AUTHORIZED SERVICE FACILITY FOR EXAMINATION AND/OR REPAIR.

DO NOT USE WITH SOMEONE WHO IS IN THE IMPOSSIBILITY OF UNDERSTANDING THESE WARNINGS.

Cautions

To avoid that objects to get in the way of the smartduvet when using the Self Making Bed feature, keep an empty space of at least 60 cm (24 inches) on the sides of the bed and 1.5 m (60 inches) over the bed (if necessary, measure the distance between the bed and any ceiling, light fixture, fan and others).


Make sure that an electrical outlet can be used to connect the power cable (ideally, use an electrical outlet at the head of the bed that allows to pass the cable below the bed or along the mattress base so people can walk freely in the room).

Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).


For appliances for altitudes exceeding 2000 m, the maximum altitude is stated Connect to properly grounded outlets only.

Do not place the device at less than 50 cm (20 inches) of a heat source.

Parts list



Duvet cover + smart layer (1)



Control box (1)




Round clips (6)



Mushroom clips (4)



Air connector with velcro (1)



Power cable (1)



L shaped velcro braket (1)

Before starting the installation Plan a work area of at least 2.5 sq.M (25 sq.ft) that is clean and free of unnecessary objects to the installation.

Make sure to have clearly identified each part included in the box. Read the procedures and, to facilitate the installation, have the parts within arm's reach in their order of integration to the device.

You will need to install an application on a smart device via an Internet connection.

Unpack your Smartduvet by removing the duvet from the reusable vacuum storage bag.



Unfold the Smartduvet with the connector tubes at the foot of the bed. Place the control box either at the end or under your bed and connect it to the power outlet using the provided power cord.



Connect the air connectors making sure the "UP" marking on the connector is facing the top of the box (the side without silicon feet.



4

Download the Smartduvet app from the App Store or Google Play Store.



5

Use the "Make the bed" function to make the bed for the first time making sure it is centered on the bed. The two metal rings at the foot corners of the bed should be aligned with the corners of the mattress



Once the Smartduvet is centered on the bed, place the corner clips under the fitted sheet to attach the fitted sheet and the flat sheet to the Smartduvet.



7

Go under the fitted and flat sheets with the clip and push it through the metal ring. For the clips at the head of the bed, only attach the flat sheet using the round clips.




8

You can choose to use either the more robust mushroom clips or the fast round clips. If you notice that the round clips are slipping off over time or while making the bed, use the mushroom clips for the 4 attach points at the foot of the bed.

Slide your hand underneath the fitted sheet and push the open clip in the metal ring and push the central part of the clip and turn it to the right to lock it in place. If you are having difficulty entering the clip because the sheets are to tight, you can use your fingers to create a space inside the ring as shown below to ease the placement of the clips. Repeat for the other central metallic ring.





9

The L Shaped velcro bracket can be bent to fit the width of your bed frame if you have a box bed, or simply inserted under your mattress or between your boxspring and mattress to secure the height of the air connectors.




10

For the clips at the head of the bed, fold your top sheet as needed to get the right tightness between the clip and the metal ring.



11

The Smartduvet should be used all night to ensure air circulation and get the most benefits. If you wish to warm up your bed, you can set up the temperature to max heat 15 minutes before going to bed, but we recommend lowering the settings to minimum while you sleep. For cooling you can use any setting.






Since the bedmaking feature depends on many factors to achieve perfect bed making, it is normal to have to adjust how you get out of bed to avoid issues with this feature.



13

Try to exit the bed by pushing the sheets over.



14

If you move a lot during your sleep, it is possible that the sheets go under the Smartduvet, making this function less effective.



15

The ambiant lighting feature can be turned on and off by pressing on the bed icon in the app. Use the slider to dim the light. For crisper colors, make sure to slide the color selector all the way to the edge of the color wheel.



16

Use the app to set the bed making function to your preferred time. Allow five minutes after each bed making for the Smartduvet to deflate back into position before using the heating and/or cooling functions.



17

The Smartduvet is equipped with a reusable air filter than can be washed in warm soapy water. It can also be infused with your favorite essential oil by adding a few drops directly on the filter providing a soothing aromatherapy experience.



Washing guide

Duvet Covers

Like a regular down duvet, Smartduvet can be used with your existing duvet cover as long as it has buttons at the foot to allow space for the air connectors. Note that the cooling effect could be reduced depending on the material.



Never wash your Smartduvet without removing the inner layer first. Only the outer layer is washable. The first step is to unzip your Smartduvet.



Remove the air connectors by pressing the tabs on each side simultaneously.



Turn your Smartduvet inside out.



Washing guide



Unfasten the seven buttons located on the four corners as well as the top middle and side buttons.



5

You can now wash your Smartduvet cover inside out in cold water on delicate, and dry it on low heat or let air dry.



6

Once your Smartduvet cover is completely dry, you can reattach the seven buttons and turn your Smartduvet rightside out.



7

Reconnect the air connectors and zip the bottom of the layer. You can now reinstall your Smartduvet by following steps 4 to 11. If the connector tabs do not clip properly, lightly push them outward until they attach securely.





Before returning the unit please contact us for further assistance as our team is dedicated in helping you to set up and enjoy your Smartduvet.

IF YOU ARE EXPERIENCING ANY PROBLEMS OR NEED
ASSISTANCE WITH YOUR UNIT
PLEASE SEND US AN EMAIL TO INFO@SMARTDUVET.COM