



Contemporary III

Mobile App Guide

Android App: View on Google Play iOS App: View on App Store

Using the Rize Contemporary III mobile app

Your adjustable bed can be controlled using your iOS or Android smart device through the Rize Contemporary III mobile app.

Before connecting your bed to the mobile app, do the following:

- Make sure your adjustable bed is plugged into a working electrical outlet and the control box is on.
- Download and install the Rize Contemporary III mobile app from the App Store®
 or the Google Play StoreTM.
- For iOS users, turn on your device's Bluetooth®. For Android users, turn on your device's Bluetooth® and Location settings.



Connecting to your adjustable bed

- 1. From your mobile device, launch the app, and then tap the gear icon to go to the Settings screen.
- 2. From the Devices list, select the your adjustable bed. The bed is listed as iFlex_[bed serial number]. Your bed's serial number is on the front cover the Owner's Manual and on the shipping carton.


To disconnect the bed from the app, tap the connected bed again.



NOTES:

- If your bed is not on the Devices list, make sure it is plugged into a working electrical outlet.
- Only one smart device can be connected per single or tandem adjustable bed.
- The bed is automatically disconnected from the app when you close the app (not running in the background) or move out of range of the connection. Pair the bed to the app again the next time you use the app.
- Pairing a smart device to the bed will unpair the remote control. The remote control can be paired to the bed again by disconnecting or unpairing the app and then pressing any button on the remote control.

Controlling the head, lumbar, and foot sections of your bed




Tap and hold the (+) or (-) buttons for the head, lumbar, or foot section of your adjustable bed to raise or lower them.

To control the head and foot sections using voice commands, tap the microphone button in the center of the screen.

NOTE: The Voice Commands List can be found on page 9.

Controlling the bed presets



Tap the preset button you want to activate. The preset buttons are ANTI SNORE, LOUNGE, ZG (Zero Gravity), INCLINE, and FLAT.

To customize the presets, adjust your bed to the desired position then tap and hold the preset button for 3 seconds.

NOTES:

- You can only customize the Lounge, Incline, and ZG buttons.
- To restore the preset positions back to factory settings, disconnect the bed from the app, and then reset the system using the remote control. For more information, see the "Resetting the system" topic on your Owner's Manual.

To activate the presets using voice commands, tap the microphone button in the center of the screen.

NOTE: The Voice Commands List can be found on page 9.

Controlling the massage feature



Tap the different massage buttons to turn on your bed's massage feature. Tap the STOP button to turn off any active massage.


To increase or decrease the massage intensity, tap and hold the (+) or (-) button.

To change the different massage feels, tap the different wave buttons.

To activate the massage feature using voice commands, tap the microphone button in the center of the screen.

NOTE: The Voice Commands List can be found on page 9.

Controlling the under-bed lights





Tap the light button to turn your under-bed lights on.

To toggle through the seven (7) colors, tap the light button several times when the light is on.

To turn off the under-bed light, tap and hold the light button for 2 seconds.

To activate the under-bed lights using voice commands, tap the microphone button in the center of the screen.

NOTE: The Voice Commands List can be found on page 9.

Controlling two adjustable beds in tandem



From the Devices list on the Settings screen, select your bed.

NOTE: The bed is listed as *iFlex_[bed serial number]*. Your bed's serial number can be found on the manual and on the box.

To connect and control a second adjustable bed, select another bed from the Devices list.

NOTE: If your second bed is not on the Devices list, make sure it is plugged into a working electrical outlet.

Once both beds are connected, the app can now operate both beds in tandem.

To disconnect the second bed, tap the bed name on the list again.



Voice Commands List

To activate the functions of your adjustable bed using voice commands, tap the microphone button in the center of your screen.

A message prompts you to say the voice command. If the command is correct, the message disappears and the bed adjusts accordingly. If the command is incorrect, a pop-up appears prompting you to speak the correct command. To dismiss the prompt after an incorrect command, tap anywhere outside the message. Tap the microphone button again to give the correct voice command.

NOTE: Make sure to speak the exact phrases in the list below for the bed to function properly according to the command.

Head Up - Lifts head section.
Head Down - Lowers head section.
Foot Up - Lifts foot section.
Foot Down - Lowers foot section.
Lumbar Up - Lifts lumbar section.
Lumbar Down - Lowers lumbar section.
Stop - Stops all lift activities.

Lounge - Activates the Lounge position.
Zero - Activates the Zero Gravity position.
Snore - Activates the Anti-Snore position.
Incline - Activates the Incline position.
Flat - Activates Flat position.

Massage On - Starts massage wave 1.
Wave One - Starts massage wave 1.
Wave Two - Starts massage wave 2.
Wave Three - Starts massage wave 3.
Massage Off - Turns massage motors off.

Light On / Lights On - Activates the under-bed light.

Toggle Lights - Toggles through the under-bed light colors.

Light Off / Lights Off - Turns the under-bed light off.



FOR ASSISTANCE, PLEASE CALL OUR CUSTOMER SERVICE TOLL FREE NUMBER

1-843-800-8372

POWERED BY CUSTOMATIC® TECHNOLOGIES™

All product names, brands, and trademarks are the property of their respective owners.

MANS5AG001 | AWMANS5AG-1 | 10.28.2019