


Don't forget to push in the lid first



The combination is index, pinky, then thumb



How to install



## ⚠ ATTENTION

Prior to using the StopBox® you must fully read and comply with all instructions and warnings of the product in the Instructions Manual. The StopBox® is intended for retaining firearms, and failure to fully read and comply with all instructions and warnings of this product could result in a firearm falling into the hands of someone other than the owner – such as a child or unwanted guest.

Failure to comply with the instructions and warnings of the StopBox® Instructions Manual could ultimately result in severe bodily injury or death. Do not place a firearm within the StopBox® until you have fully read all instructions and warnings contained in the Instructions Manual and any other manuals or documentation that accompany the product.

StopBox USA, LLC shall not be liable for any injury, loss or damage, direct or consequential arising out of the use of, or the inability to use the StopBox®. You shall determine the suitability of the StopBox® before intended use and you assume all risk and liability whatsoever in connection therewith.

FAILURE TO COMPLY WITH THE STOPBOX® INSTRUCTIONS MANUAL, OR ANY OTHER MANUALS OR DOCUMENTATION THAT ACCOMPANY THIS PRODUCT WILL RESULT IN THE LIMITED WARRANTY CONTAINED HEREIN TO BECOME VOID. ADDITIONALLY, THE LIMITED WARRANTY CONTAINED HEREIN WILL BECOME VOID IF YOU (1) SUBJECT THE STOPBOX® TO ANYTHING BEYOND ORDINARY AND INTENDED USE, (2) MODIFY, ALTER OR DECONSTRUCT THE STOPBOX®, OR (3) USE THE STOPBOX® IN VIOLATION OF ANY APPLICABLE LOCAL, STATE OR FEDERAL RULES, LAWS OR REGULATIONS.

The Instructions Manual can be found at [www.StopBoxUSA.com](http://www.StopBoxUSA.com)



**TIP:** Be sure to write down and save the code stamped on your keys. If you were to lose your keys we can use this code to send you replacements.



Thank you for purchasing the StopBox® Wall-Anchored Retention Device. Before using the StopBox® please read carefully all the warnings and safety precautions included in this manual.

The StopBox® WARD is designed to conceal and prevent unintentional access while your firearm is not on your body. You shall determine the suitability of the StopBox® to your specific situation and needs.

### SPECIFICATIONS

- Polycarbonate-ABS construction
- Exterior: 11.25" x 7.9" x 2" | Interior: 8" x 5.75" x 1.5"
- Weight: 2.6 lbs

You should seek proper firearm safety training before owning and using a firearm.

Never leave a loaded firearm unattended.

The StopBox® is intended for retaining your firearm, aiding in restricting immediate unintentional access.

Never allow children to play with or handle the StopBox®.

Regularly inspect the StopBox® for damage or wear. If the StopBox® is damaged or not functioning properly stop using immediately and replace it.

**CAUTION:** Many lubricant additives will attack plastic materials causing cracking and failure. If you need to lubricate the StopBox® we recommend using Super Lube® Multi-Purpose Synthetic Grease.

**ALWAYS** follow the four rules of gun safety.

Treat every gun as if it is loaded, even if it is not.

Always keep your finger off the trigger until you are ready to fire.

Never point a gun at something you are not willing to destroy.

Always know your target and what is beyond it.

### UNLOCKING

1. Index your hand on the corner of the enclosure and align your fingers with the 5 finger actuators.
2. Press and hold the pinky and index finger actuators simultaneously. Note: pinning the StopBox® lid down with your palm.
3. While applying pressure on the enclosure press the Thumb Lock and lift open.

The combination by default is set as the pinky and index finger but can be changed to fit your needs. There are six configurable combinations with the included hardware. For additional combinations the Actuator Accessory Pack can be purchased at [www.StopBoxUSA.com](http://www.StopBoxUSA.com)

### LOCKING

Make sure any contents are within the inside barriers then firmly press the center of the enclosure lid shut. **IMPORTANT:** Make sure both locks have successfully engaged. If only one side of the StopBox® is locked the other can be pried open. Visually check that there is equal gap at both ends of the enclosure and that the enclosure is secure.

### TROUBLESHOOTING

If the Thumb Lock is not springing back into place when the StopBox® is closed, open and insure the Lock Bar springs are properly installed and not bound in the retainers.

### MAINTENANCE

Periodically check that all screws are tightly fastened.

### CHANGING THE COMBINATION

To change the combination please refer to our instruction video at: [www.StopBoxUSA.com/stopbox-instructions](http://www.StopBoxUSA.com/stopbox-instructions)

If you have questions please contact us at [support@stopboxusa.com](mailto:support@stopboxusa.com) or (509) 919-4600.

### LIFETIME WARRANTY

Limited Lifetime Manufacturer's Warranty: StopBox USA, LLC (StopBox USA) is proud of the workmanship of the product you have just purchased. StopBox USA warrants that each new StopBox® will be free from defects in material and workmanship for the lifetime of the original purchaser. If there is a defect in either materials or workmanship during your lifetime, we will repair or replace your StopBox® at no cost to the purchaser.

StopBox USA's obligation under the Limited Lifetime Manufacturer's Warranty is limited to the repair (including labor) or replacement of any product that proves to be defective. Claims shall be made under this warranty by calling 509-919-4600, emailing [support@stopboxusa.com](mailto:support@stopboxusa.com) or writing to StopBox USA, 932 N Lake Rd Spokane Valley, WA 99212.

StopBox USA takes seriously its obligation to stand behind its product with this warranty as long as the StopBox® is properly cared for as instructed in the Instructions Manual. The warranty does not apply to the StopBox® or parts that have been misused, neglected or subjected to unusual or extreme conditions and/or environments, or to unreasonable wear and tear. Changing or modifying the StopBox® in ways that affect its intended use will void this warranty.

Limitation of Remedies: In no case shall StopBox USA be liable for any special, incidental, or consequential damages based upon breach of warranty, breach of contract, negligence, strict tort, or any other legal theory. Such damages include, but are not limited to, loss of profits, loss of savings or revenue, loss of the contents of the StopBox®, loss of use of the StopBox® or any associated equipment, cost of capital, cost of any substitute equipment, facilities or services, downtime, the claims of third parties including customers, and injury to property.

No Other Warranties: This agreement is understood to be the complete and exclusive agreement between the parties, superseding all prior agreements, oral or written, and all other communications between the parties relating to the subject matter of this agreement. No employee of StopBox® or any other party is authorized to make any warranty in addition to those made in this agreement.

THIS WARRANTY PERTAINS ONLY TO THE STOPBOX® ITSELF, AND DOES NOT EXTEND TO THE CONTENTS OF THE STOPBOX®.

Disclaimer of Warranty:

THE ABOVE WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH EXTENDS BEYOND THE WARRANTY SPECIFIED ABOVE, AND IN NO EVENT SHALL THIS WARRANTY BE DEEMED TO COVER INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND.

Venue and Choice of Law: Any claims arising from this limited warranty shall be resolved in the State of Washington and Washington law will apply to any dispute.