

# Caravan Towing Cover

## Fitting Guide

We recommend that you will need two people to fit this cover.

Before fitting your cover please ensure that your caravan front is clean to avoid trapping dirt underneath which could cause scratching to the caravan.

When unpacking the cover take care not to pick up any dirt or debris from the ground as this again can cause scratching.

## First time fitting

- Release all the adjustable straps to allow enough width for your caravan
- With one person either side of the cover slide the beading in to the awning channel from either the top or the bottom, depending on the style of your caravan awning channel.
- Check that the cut out for the A frame is in the right position before equally adjusting the side straps.
- When all seven pairs of straps are in place and the cover looks central carefully tighten each strap. **Please do not over tighten the straps.**
- Once the side straps have been secured make sure the A frame strap is connected securely. **Again please do not over tighten.**
- Secure any excess from the straps by wrapping them around itself. This is to stop them from flapping around whilst being towed.
- To remove the cover loosen the side straps just sufficient to allow the cover to slide off. This will then make re fitting easier.

## Cleaning Guide

When needed wash with a sponge and soapy water then rinse with clean water.

## DO NOT MACHINE WASH

Protects your caravan from:



Bug Splat



Dirt



Stone Chips



Light Reflection