

Jetson



SATURN KICK SCOOTER

-MANUAL-

TABLE OF CONTENTS

1. INTRODUCTION	4
2. INCLUDED IN THE BOX	5
3. FEATURES AND SPECS	5
4. UNFOLDING AND FOLDING	6
5. ADJUSTING THE HANDLEBAR	7
6. HOW TO CHANGE BATTERIES	7
7. LEAN TO STEER	9
8. FOOT POSITION	9
9. HOW TO APPLY THE BRAKE	9
10. SAFETY WARNINGS	10
11. WARRANTY	12
12. PRODUCT REGISTRATION	14

INTRODUCTION


Congratulations on your new Jetson Saturn Kick Scooter! The Saturn is an innovative and fun kick scooter, ready to take on everyday use. Before your first ride, check whether the wheels are damaged, or parts are loose. If there are any abnormalities, please contact Jetson Customer Support at 1-(888) 976-9904 or email us at customerservice@jetsonbike.com.

This product manual can help you understand, use, and maintain your Saturn. In order to avoid danger caused by collisions, falls, and loss of control, please use caution and learn how to ride the Saturn safely. Jetson and authorized dealers cannot be held liable for injury or damage caused from riding the Saturn. Users ride at their own risk.

The rider is responsible for consequences caused by violating warnings or improper operations.

If you want to return this product for any reason, be sure to first call or email us before taking it back to the store so we can assist you.

INCLUDED IN THE BOX



1. Handlebar
2. Stem
3. Stem LED Lights Switch
4. Deck


5. Push Button
6. Folding Button
7. LED Light Up Wheels

FEATURES AND SPECS

- Weight Limit: 110 lbs
- Product Weight: 9 lbs
- Recommended Age: 3+
- Wheels Size: 120 x 55 mm Front Wheels
- Rear Foot Brake
- Adjustable Handlebar
- LED Light up Wheels
- LED Light up Stem and Deck
- Easy Folding Mechanism
- Lean to Steer

UNFOLDING AND FOLDING

To unfold the Saturn, push in the Folding Button at the bottom of the Stem and lift the Handlebar up. Once brought to a 90-degree angle the button will click. Make sure the Handlebar and Stem are locked in to place before riding. (Please Note: Images may differ from actual product).



To fold the Saturn, push in the Folding Button at the bottom of the Stem and push the Handlebar down towards the Deck. Once completely folded, the button will click. Make sure the Handlebar and Stem are locked into place.



ADJUSTING THE HANDLEBAR

To Adjust the Handlebar, push out the Stem Clamp and turn the Knob counterclockwise to loosen (make sure you do not remove the Knob completely.) Press the Push Button on the Stem in. Lift or lower the Handlebar until it clicks and suits the height of the rider. Once fully adjusted turn the Knob clockwise and push in the Stem Clamp to secure.



HOW TO CHANGE THE BATTERIES

The Saturn has LED lights located in the Stem, the Deck, and the Wheels. In order to have the Stem and Deck illuminate, you will need to add a total of 6 AAA batteries; 3 AAA batteries to the Stem and 3 AAA batteries to the bottom of the Deck.

Use a screw driver to open the battery box at the bottom of the Stem and place batteries inside. Close the battery box door with the screw and screwdriver. The LED Lights in the Stem are now ready to be turned on. In order to illuminate the Stem, you will need to turn on the Stem LED Light Switch located on the front of the Saturn near the base of the Stem.



Stem
Battery Box

BACK VIEW

To insert the batteries in the Deck, flip over the Saturn so you are looking at the bottom of the Deck.

Use a screw driver to open the battery box at the bottom of the deck and place the batteries inside.



Deck
Battery Box

Deck Light
Switch

Close the battery box door with the screw and screwdriver. The LED Lights in the Deck are now ready to be turned on. In order to illuminate the Deck, you will need to turn on the Deck LED Light Switch.

To save battery life, remember to turn off the LED lights at the end of every ride.

The wheels are equipped with LED lights that will illuminate when riding, they do not require any batteries.

LEAN TO STEER

The Lean to Steer function makes it easy to steer the Saturn, just shift your weight in the direction you would like the Saturn to go. Be careful to not lean too hard on the handlebars.

FOOT POSITION

Before riding, put your foot as close as possible to the front of the Deck, and your other foot on the ground. Make sure that your driving route is clear. To start riding, boost yourself forward with your foot that is on the ground. Keep one foot behind the other, (it's more comfortable to place one foot forward and the other one turned backwards at 70-90°, like on skate/surfboard). It will help you gain more stability.

HOW TO APPLY THE BRAKE

To apply the brake, press down on the Rear Brake with your back foot.



SAFETY WARNINGS

- This product is suitable for children age 3+, and for use on private property and closed courses. Always ride defensively, and watch out for potential obstacles that may catch your wheel or cause you to swerve suddenly.
- The Saturn should always be used under adult supervision.
- Always check any local laws or regulations which may affect where the Saturn may be used.
- Ride at your own risk and use common sense. Any rider that is unable to fit comfortably on the product should not attempt to ride it. All decisions on who is allowed to ride the Saturn should be made based on their maturity, skill, and ability to follow the rules.
- The Saturn is designed for one rider. Never carry passengers, and do not attach the Saturn to other objects.
- This product was manufactured for performance and durability, but is not impervious to damage. Jumping and aggressive riding should be avoided under all circumstances. The rider assumes all responsibility and risk associated with high-stress activity.
- Keep your fingers and other body parts away from all other moving components when operating the Saturn. Keep your hands on the handlebars at all times.
- Do not wear headphones or use a cell phone while operating the Saturn.
- Do not operate the Saturn in wet or icy weather, and never immerse the product in water.
- Avoid excessive speeds when riding downhill, as it increases the risk of accident and injury. Avoid wet, slick, bumpy, uneven or rough surfaces while using the Saturn. Never risk damaging surfaces such as carpet and flooring by using the product indoors.
- Do not ride at night, or when visibility is limited.

- Always wear proper protective equipment, such as a helmet, elbow pads, and knee pads. Athletic shoes with rubber soles are best for riding the Saturn.
- Never operate the product barefooted or in sandals, and keep shoelaces tied and away from the wheels.
- The brake may become hot while operating, do not touch the brake with your bare skin.
- Make sure all screws are tightened, and all clamps and locks are properly secured before riding.

CALIFORNIA WARNING

This product contains chemicals, including lead, which are known to the state of California to cause cancer, birth defects, and other medical conditions.

MODIFICATIONS

Do not attempt to disassemble, modify, repair, or replace the Saturn unit or any components of the unit. This will void any warranty, and can lead to malfunctions which may cause injury.

ADDITIONAL OPERATION CAUTIONS

Do not lift the Saturn off the ground while it is in operation and the wheels are in motion. This can result in freely spinning wheels, which may cause injury to yourself or others nearby. Do not jump on or off the Saturn, and do not jump while using it. Always keep your feet firmly planted on the deck while riding.

LIMITED 1 YEAR WARRANTY

TO QUALIFY FOR WARRANTY SERVICE:

1. You must present a copy of the sales receipt from an approved retail partner within 90 days of purchase.
2. This product cannot be used for rental or commercial use.
3. This product cannot be used for competition.

LIMITATIONS OF LIABILITY

- This Limited 1 Year Warranty is non-transferable after the product's initial sale.
- No unapproved modifications can be made to the product, its performance or otherwise, in order for this Limited 1 Year Warranty to remain in effect.
- No reimbursement is provided for towing, loss of time, loss of use, inconvenience, incidental or consequential damages.
- Warranty is void if weather related water damage is determined. Owner is responsible for storage and protection from weather.
- Jetson® makes no warranty with respect to products or trade accessories not made by Jetson®, including, but not limited to, motors, tires, wheels, and batteries, such products or trade accessories, such items being subject to the original manufacturer's warranty, if any.
- This Limited 1 Year Warranty does not cover minor surface blemishes, rips, tears, or other cosmetic damages due to normal use, or other intentional or unintentional damage to the product.
- This Limited 1 Year Warranty will not cover any damage which results from the application of improper cleaners, solvents or chemicals to the product, water damage, smoke or soot, or from exposure to saltwater, sea breeze or salt.
- This Limited 1 Year Warranty will not cover any damage which results from aging, such as fading of paint, deterioration of plated surfaces, deterioration of rubber or plastics, or rusting.
- This Limited 1 Year Warranty does not cover improper repair or misdiagnoses of problems.
- This Limited 1 Year Warranty only covers parts due to manufacturer defect.
- Damage due to misuse or neglect, use other than as specified in the Owner's Manual, or use under abnormal conditions are not covered by this Limited 1 Year Warranty.

OWNER'S WARRANTY RESPONSIBILITIES

As the device's owner, you are responsible for the performance of the required maintenance. You may be denied a warranty claim solely because of your failure to ensure the performance of all scheduled maintenance. As the owner, you should be aware that you may be denied your warranty coverage if your device or a part has failed due to abuse, neglect, improper maintenance, or unapproved modifications. For any issue regarding your Jetson® product, call toll free **1-(888) 976-9904**, or email [**customerservice@jetsonbike.com**](mailto:customerservice@jetsonbike.com).

PRODUCT REGISTRATION

Please complete and mail this card within 10 days of purchase or go to <https://www.ridejetson.com/product-registration>.

Name: _____

Address: _____

City, State, Zip: _____

Email: _____

Home Phone: _____ Gender: _____

Purchase Date: _____ Purchased From: _____

Serial Number: _____

Is this your first Jetson product?: _____

Other similar product owned before: _____

- Why did you buy this product?:
- For myself
 - For my child
 - For my grandchild
 - Gift for someone else (adult)
 - Gift for someone else (child)

How did you hear about the Jetson Saturn?: _____

Complete this form and mail it to:

**Attention: Product Registration
Jetson Electric Bikes
1 Rewe Street
Brooklyn, NY 11211**

Jetson



SATURN KICK SCOOTER