


TABLE OF CONTENTS

What's in the Box	1
Features and Specs	2
Charging the Battery	3
Indicator Lights	4
How to Recalibrate	5
Riding the V6	6
Connecting to Bluetooth®	7
Care and Maintenance	8
Safety Warnings	9

1. WHAT'S IN THE BOX



2. FEATURES AND SPECS

V6 LIMITED

- Weight Limit: 300 lbs.
- Product Weight: 23 lbs.
- Recommended Age: 13+
- Tire Size: 8"
- Max Speed: Up To 10 mph
- Max Range: Up To 15 miles
- Battery: 36V, 4.4 Ah Lithium Ion
- Motor: 700W (350W*2), Dual Hub Motor
- Charger: 110-240V
- Charge Time: Up To 2 Hours
- Climbing Angle: Up To 20°
- Galaxy Light-Up Wheels


3. CHARGING THE BATTERY

A few must-do's:


- Only use the included charger.
- Plug the charger into the wall before the Charging Port.
- Don't turn on the V6 while it's charging (it needs its rest).
- Charge the battery until it is fully charged up to 2 hours.
- Do not overcharge, the battery life will be affected.
- Replace the cover over the Charging Port when done.
- Remember to have fun!

CHARGING INDICATOR ON THE CHARGER:

Red Light: Battery is charging. Green Light: Charging is complete.




4. INDICATOR LIGHTS



1. BATTERY INDICATOR LIGHTS -

- Green light Over 50% power.
- Yellow light 49-20% power.
- Red light Less than 20% power. Time to charge! (Warning: If the battery power goes below 10%, the V6 will automatically turn off as a safety precaution.)
- 2. STATUS INDICATOR LIGHTS The Active Balance Technology has kicked in, which will help you stay leveled as you ride.


5. HOW TO RECALIBRATE




If the Status Indicator Light turns red or if you are having issues with the V6, you may need to recalibrate it. Follow these steps...

- 1. Place the V6 on a flat, level surface. Now say something nice to it. Just kidding, but, go ahead if you like.
- 2. Hold the Power Button (for about 5 seconds) until you are notified of a successful recalibration.
- 3. Restart the V6 by turning it off and then on.
- 4. You're all set! The V6 is ready to roll.


6. RIDING THE V6



TURN LEFT



TURN RIGHT



7. CONNECTING TO BLUETOOTH®

The V6 comes equipped with two Bluetooth® modules - one for the Bluetooth® speaker and one for the Ride Jetson app.

To connect to your Bluetooth® speaker:

- Turn on the V6, and it will become discoverable to your handheld device.
- Activate your Bluetooth® in your handheld device's settings.
- Find the V6 in your handheld device's list and select it.
- Now you can play your awesome tunes.

To connect to the Ride Jetson app:

- Open the Ride Jetson app on your handheld device.
- Tap the Bluetooth® symbol in the top left corner of the app.
- Select your V6. Default password is "000000." (To customize your password go to Settings in the App. If you forget your new password, you can factory reset the V6 by recalibrating)
- You should now be connected to the V6!

MODE SETTINGS

In the Ride Jetson app you can choose from three settings:

- Beginner mode max speed: Up to 6 mph
- Intermediate mode max speed: Up to 8 mph
- Advanced mode max speed: Up to 10 mph

NOTE: Other features that can be adjusted include Steering Sensitivity, Driving Force, and Auto Shutdown Time.

8. CARE AND MAINTENANCE

RIDING RANGE

The maximum range is 15 miles. However, a lot of factors will affect how far you can go per charge:

- Driving Surface: A smooth, flat surface will increase driving distance.
- · Weight: More weight means less distance.
- Temperature: Ride and store the V6 above 50°F.
- Maintenance: Timely battery charging and maintenance will increase driving distance.
- Speed and Driving Style: Frequent starting and stopping will reduce driving distance.

CLEANING THE V6

To clean the V6, carefully wipe with a damp cloth, then dry with a dry cloth. Do not use water to clean the V6, as the electrical and electronic systems may get wet, resulting in personal injury or malfunction of the V6.

BATTERY

- Keep the V6 away from fire and excessive heat.
- Do not subject the V6 to intense physical shock, severe vibration, or impact.
- Protect from water or moisture.
- Do not disassemble the V6 or its battery.
- If there are any issues with the battery, please contact Jetson Customer Support.

STORAGE

- Fully charge the battery before storing. The battery should be fully charged once a month after this.
- To protect against dust, cover the V6.
- Store the V6 indoors, in a dry place and at a suitable temperature.
- You should bring the V6 into a warm environment for charging.

9. SAFETY WARNINGS

- For your safety, please read the user manual and safety warnings carefully, and make sure you understand and accept all the safety instructions. The user will be responsible for any loss or damage caused by improper use.
- Children, the elderly, pregnant women, and those with heart conditions should not use the product.
- The rider should not exceed 300 lbs.
- Do not ride at night.
- Do not use near motor vehicles.
- Do not ride after drinking or taking prescription medication.
- Do not ride the product if you have had any head, back, or neck ailments, or prior surgeries to those areas.
- Persons with any mental or physical conditions that may make them susceptible to injury or impair their dexterity or mental capabilities should recognize, understand, and perform all of the safety instructions and be able to assume the hazards inherent in using the product.
- Do not carry items when riding.
- Always wear shoes, a helmet, and appropriate safety gear.
- Prior to each ride, inspect each part of the product to ensure it has been maintained correctly and is functioning properly.
- Always give way to pedestrians.
- Always comply with local traffic laws and regulations.
- Be alert to things in front and far away from you.
- Make sure your feet are always placed securely on the deck.
- The product cannot be ridden by more than one person.
- When you ride the product along with other riders, always keep a safe distance to avoid a collision.
- When turning, be sure to maintain your balance.
- Do not allow distractions when riding, such as answering the phone or engaging in any other activities.
- Avoid riding in the rain or on smooth surfaces such as snow or ice.
- Do not ride on roads with obstacles (such as litter, small stones, etc.).
- Avoid riding in narrow spaces or on steep slopes.
- Avoid riding around flammable gas, steam, liquid, or dust that could cause fire.
- Never operate the products barefooted and keep shoelaces tied.
- Riding with improperly adjusted brakes is dangerous and can result in serious injury or death.

- Applying brakes too hard or too suddenly can lock up a wheel, which could cause you to lose control and fall. Sudden or excessive application of the brake may result in injury or death.
- Do not ride without proper training. Do not ride at high speeds, on uneven terrain, or on slopes. Do not perform stunts or turn abruptly.
- The area that the product is to be operated should be safe and suitable for safe operation.
- · Check whether all safety labels are in place and understood before riding.
- The owner shall allow the use and operation of the unit after a demonstration that such operators can understand and operate all components of the unit before use.
- Operators shall adhere to all of the manufacturer's recommendations and instructions, as well as comply with all laws and ordinances.
- Only ride the product with adequate daylight conditions for visibility.
- We encourage you to highlight the product, for visibility, by using lighting, reflectors, and signal flags on flexible poles.

CALIFORNIA PROPOSITION 65

▲ WARNING: This product can expose you to a chemical such as Cadmium that is known to the State of California to cause cancer or birth defects or other reproductive harm. For more information go to www.p65warnings.ca.gov/product

MODIFICATIONS

Do not attempt to disassemble, modify, repair, or replace the product or any components of the unit without instruction from Jetson Customer Support. This will void any warranty, and can lead to malfunctions which may cause injury.

ADDITIONAL OPERATION CAUTIONS

Do not lift the product off the ground while it is on and the wheels are in motion. This can result in freely spinning wheels, which may cause injury to yourself or others nearby. Do not jump on or off the product, and do not jump while using it. Always keep your feet firmly planted on the deck while in operation. Always check the battery charge before using.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



1-(888) 976-9904 • help@ridejetson.com • www.ridejetson.com









