ARIESGOLD MCMLXX

L 5027 / CAL. VX00A1, VX11B2

USER MANUAL

All specifications are subject to change without prior notice.

DUAL TIME

/ TIME STANDARD

Type of Quartz : Tuning fork
Frequency : 32,768Hz

Accuracy : ±20 seconds/ month (on wrist)

/ FUNCTION

[VX00A1] 2 Hands : Hour/ Minute

[VX11B2] 3 Hands : Hour/ Minute/ Second

Reset Switch

/ INSTRUCTION MANUAL

[Displays & Buttons]



VX00A (2 HANDS)

- 1. Crown at normal position: Free
- 2. Crown pulled out 1st click: Time setting/ Reset

VX11B (3 HANDS)

- 1. Pull crown out when the second hand is at the 12 o'clock position.
- 2. Turn the crown to set the time.

Note: When setting the minute hand, advance it 4 to 5 minutes ahead of the desired time and then turn it back to the exact time.

3. Push crown back to normal position. See the second hand begins to run.