Bullard

1898 Safety Way Cynthiana, KY 41031-9303 877-BULLARD (285-5273)

Model GenVX Series

Type C Continuous Flow Supplied-Air Respirator Approved Only in the Following Configurations:



RESPIRATOR COMPONENTS												
TC-	PROTECTION	MODEL	HOOD	BREATHING TUBE	ALTERNATE CAPE ASSEMBLIES		ALTERNATE FLOW CONTROL DEVICE	AIR HOSE	ACCESSORIES	ALTERNATE SUSPENSIONS	ALTERNATE LENSES	CAUTIONS AND LIMITATIONS ²
		GENVX SERIES RESPIRATOR	GENVX			360RVX 130KX 1316/X 160/X 66/X PKXY PKXLYX 36/X 36/X 36/X	HC240 HC240 HC240 HC244 HC24 HC241 HC241 HC241 HC241 HC241	V201			GVXLL GVXLT GVXOL40 GVXOL40 GVXDL5 GVXLC	
19C-0492	SA/SB/CF	GENVX	Х	Х	XXXXXX	XXXXXXXXXX	x x x x x x x x x x	x x x x x x x x x x x x x x x x x x x	хххх	ХХ	x x x x x x	ABCDEJMNOS

1. PROTECTION

MNN SERVICE

CF=Continuous Flow

SB=Supplied - Air Abrasive Blast

SA=Supplied - Air

2. CAUTIONS AND LIMITATIONS

A - Not for use in atmosphere containing less than 19.5 percent oxygen.

- B Not for use in atmospheres immediately dangerous to life or health.
- C Do not exceed maximum use concentrations established by regulatory standards.
- D Air-line respirators can be used only when the respirators are supplied with respirable air meeting the requirements of CGA G-7.1 Grade D or higher quality.
- E Use only the pressure ranges and hose lengths specified in the User's Instructions.
- J Failure to properly use and maintain this product could result in injury or death.
- M All approved respirators shall be selected, fitted, used and maintained in accordance with MSHA, OSHA and other applicable regulations.
- N Never substitute, modify, add or omit parts. Use only exact replacement parts in the configuration specified by the manufacturer.
- 0 Refer to User's Instructions, and/or maintenance manuals for information on use and maintenance of these respirators.
- S Special or critical User's Instruction and / or specific use limitations apply. Refer to User's Instructions before donning.