

CARE AND MAINTENANCE:

For better protection of this product, never unfold or inflate the airbed in temperatures below freezing, avoid extensive exposure to the sun and protect from contact with sharp objects and rough ground.

Make sure to handle the pump with care. Clean air beds only with mild soap and water. Pump gasket may need occasional lubrication to maintain a positive seal. Storage at high temperatures may reduce battery life.

NOTE:

Air bed material may stretch during first use and may need additional air to reach desired firmness.

Air inside of bed may expand and contract with varying temperatures potentially leading to reduced pressure inside of bed.


REPAIRING: (Repair Patch Included)

For small puncture holes, tears or cuts, cut a small piece of PVC patch material (included) and apply patch. Allow at least four (4) hours for repair to set before attempting to inflate the air bed.



 <p>0-15 MONTHS</p>	<p>⚠ WARNING</p> <p>RISK OF SUFFOCATION</p> <ul style="list-style-type: none">• Infants have suffocated on inflatable mattresses. Never place infant aged birth to 15 months to sleep on this inflatable air mattress/air bed. Infancy can suffocate on an under-inflated or deflated mattress, on bedding, by co-sleeping with another person, and by entrapment between the mattress and bed frame or between the mattress and a vertical surface.• Children can be entrapped between the inflatable mattress and an adjacent vertical surface.• Provide at least a shoulder width space between the inflatable mattress/air bed and adjacent vertical surfaces such as walls, dressers, or other objects.• Always keep the inflatable mattress fully inflated when in use.
--	--

WARNING:

1. Charge only with the transformer provided with the pump.
2. Plug AC charger into 120V AC electrical outlet to charge with the AC adaptor.
3. Plug car charger into 6V car cigarette lighter socket to charge with the car charger.
4. Electric pump must be switched to OFF position when charging.
5. Do not drop unit into water. Serious injuries or death by electrocution may occur.
6. Do not charge the pump in temperatures below 41F (5C) or higher than 104F(40C)
7. Do not use in wet conditions.
8. Do not over inflate.
9. For proper pump usage, do not exceed 5 minutes of inflation/deflation time.
10. Do not use as a water floatation or as a life saving device.
11. To keep the battery at optimum operating condition, always store pump with a full charge, recharge the pump once a month even if it has not been used.
12. Never allow sand, small rocks or any objects to be sucked into the pump while operating.
13. Make sure to replace the charger connector cover after use.
14. Do not insert any metal object into the charger connector.
15. Do not try to disassemble, repair or service the pump or individual parts. Once the pump is disassembled, the warranty will be invalid.



TO CHARGE:



When charging your electric pump, please make sure the Pump Switch is in the "OFF" position, your pump will not charge when the Pump Switch is in the "ON" position.

TO CHARGE WITH AC OUTLET:


Turn the Pump Switch to the "OFF" position, plug AC charger into 120V electrical outlet and connect charger with the Charger Connector on pump.

TO CHARGE WITH CAR CHARGER:


Turn the Pump Switch to the "OFF" position, plug Car Charger into 6V cigarette lighter socket in car and connect charger with the Charger Connector on pump.

NOTE: PUMP MUST BE CHARGED FOR 12 HOURS PRIOR TO FIRST USE.


TO INFLATE



1. Before inflation, make sure the Valve Switch (yellow) is fully retracted. If it is not fully retracted, gently pull on the Valve Switch to ensure air lock.




2. Turn the Pump Switch to the "ON" position. Upon reaching desired firmness, turn the Pump Switch to the "OFF" position and replace the Valve Cap.




3. Upon reaching desired firmness, turn the Pump Switch to the "OFF" position. Check if the Valve Switch (yellow) is fully retracted. If it is not fully retracted, gently pull on the Valve Switch to ensure perfect air lock, and fasten cap on the Valve. Your air bed is now ready for use.

TO DEFLATE



1. Before deflation, release the Valve Cap and gently push in the Valve Switch (yellow).



2. Turn the Pump Switch to the "ON" position. Upon complete deflation, turn the Pump Switch to the "OFF" position and replace the Valve cap, your air bed is ready for storage.