




DME SYSTEM M 09 CONNECTOR ASSIGNMENT

Vehicle: Connector Views



1. Oxygen Sensor Heating Behind Catalytic Converter
2. Idle Air Control Valve, Closing Coil
3. Full Injector, Cylinder 1
4. Full Injector, Cylinder 2
5. Full Injector, Cylinder 3
6. Ground
7. not assigned
8. Malfunction Indication Light Check Engine
9. not assigned
10. not assigned
11. not assigned
12. Crash Signal (Airbag)
13. Knock Sensor 1 (Cyl. 1-3)
14. Medium Pressure Switch (Air Conditioning)
15. Intake Air Temperature Sensor
16. Engine Compartment Temperature Sensor
17. Signal, Mass Air Flow Sensor
18. Signal, Oxygen Sensor 2 Ahead of Catalytic Converter
19. Signal, Oxygen Sensor 1 Ahead of Catalytic Converter
20. Ground, Speed Sender
21. Signal, Camshaft Position Sensor 1+2
22. Ignition Coil, Cyl. 4, Terminal 1
23. Ignition Coil, Cyl. 3, Terminal 1
24. Ignition Coil, Cyl. 5, Terminal 1
25. Camshaft Adjustment, Bank 2
26. Terminal 30
27. Triggering of ECM Relay, Terminal 85
28. Ground, Electronic System
29. Idle Air Control Valve, Opening Coil
30. Oxygen Sensor Heating Ahead of Catalytic Converter
31. Fuel injector, Cylinder 6
32. Fuel injector, Cylinder 4
33. Fuel injector, Cylinder 5
34. Ground, Sender
35. Coolant Fan, Stage 1
36. Coolant Fan, Stage 2
37. Triggering of Relay, Secondary Air Pump
38. Version coding (Ground for Tiptronic)
39. Fuel Level Pilot Light
40. not assigned
41. Knock Sensor 2 (Cyl.4-6)
42. Automatic I/M Test
43. not assigned
44. Signal, Throttle Sender
45. Ground, MAF Sensor