

Multi-zone Weather Station with Atomic Time
(3 remote sensors included)

SET-UP GUIDE

- Remove plastic film from the clock display and from each sensor.
- Remove the battery doors of the clock and remote sensors.
- Insert 4 x AA batteries in the clock and replace battery cover.
- On the back of each remote sensor there is a switch under the battery cover. Set the switches to 1, 2 or 3 on each one, so that each remote is different.
- Insert 2 x AA batteries into each remote sensor. (Don't put the battery covers on yet.)
- To pair the Remote Sensors with the clock, press and release the [CH +] button on the back of the clock to select Channel 1, then press and release the [SENSOR] button.
- (Note: Do this step within 8 seconds of step 6.) Press the [RESET] button on the back of the Remote Sensor that is set to 1. Once the information from Remote Sensor 1 is displayed on the main unit, repeat the same steps for the other two Remote Sensors.
- Put the battery covers back on the remote sensors.
- Press and hold the [CH +] button on the back of the clock for 3 seconds to enable the Remote Sensor channels to rotate on the main unit display.
- Press and release the [CH +] button to lock a specific channel display and disable the scrolling of the channels.
- NOTE: The Remote Sensors display temperature in °F only. The main unit displays the temperature in °C or °F. Select °C or °F using the switch on the back of the main unit.

SET YOUR TIME ZONE

1. The default time zone on the clock is PST. If you are in another time zone, press and hold the [TIME SET] button for 3 seconds to enter setting mode.
2. The 12/24 time format will flash. Press the [TIME SET] button repeatedly in the setting mode until the time zone flashes in upper right corner of display.
3. Setting mode sequence: 12/24 hr → Hour → Minute → Second → Time Zone
4. Use the [CH +] or [MEM -] buttons to scroll through the 4 time zones and select yours.
5. Press and release the [TIME SET] button to exit the setting mode.
6. Press and release the [RCC] button to activate the time signal reception.*
7. Place the clock close to a window and allow 24-48 hours for it to receive the radio time signal.
8. (To set the time manually, refer to the instruction manual.)

Questions? Call 1-800-822-4329

Or send an email (include your telephone number) to service@marathonwatch.com and it will be answered within 24 hours.

Customer service hours are Monday to Friday between 9:00am to 4:30pm EST.

*Radio signals are strongest at night. Metal window frames or concrete walls may interfere with radio signals. Allow 24-48 hours for the clock to pick up the radio time signal. Each clock has been inspected and tested.