

INSTRUCTION GUIDE

Festoon Lights

Model # SLDFES-10WW, SLDFES-20WW, SLDFES-20CLD

INSTALLATION METHOD

- Remove contents from packaging, make sure to switch them "ON" before installation
- 2. Locate desired location for panel (Spike or wall mount using the supplied screws) & install in a position where the panel will receive maximum direct sunlight during the day
- 3. Connect cable from festoons to solar panel cable

*An initial charging time before first use of <u>no less</u> than **8hrs** for **Option 1** & **4hrs** for **Option 2** is recommended*

CHARGING OPTIONS





Option 1

Charge by direct sunlight

This way is recommended during days the panel will receive sufficient sunlight to charge

Option 2

Charge by 5v USB Port

This way is recommended for overcast and rainy days when the panel will not receive sufficient sunlight to charge

INDICATOR LIGHTS






Figure 1

RED – Charging
GREEN – Fully Charged

TROUBLE SHOOTING

Problem	Cause	Inspection Method	Solution
Light won't turn on	Switch hasn't been turned on	Determine what position the switch is in	Turn the switch on
	Battery has run flat	Period of rainy or cloudy weather or installation site doesn't provide enough direct sunlight	Charge the light in direct sunlight for 1-2 days then check again Charge light via the USB port (Option 2)
Light won't turn on/not all lights working	Bulbs not making contact with copper tab inside lamp holder	Unscrew light bulbs and locate copper tab inside lamp holder	Gently lift copper tap inside the lamp holder in order to make contact with the bottom of the bulb, ensure the fitting is off when doing so
Short operating time	Low Battery	Bad installation site for the Solar Panel Dust or leaves are covering the panel Long period of overcast weather	1. Charge the battery in direct sunlight for 1-2 days with switch off, then check again 2. Clean the solar panel 3. Charge the light via USB port (Option 2)
	Battery Failure	Remove rear cover of solar panel & replace battery Battery has matured	Contact SLD Customer Support to buy new batteries

LIGHT OPERATING MODES



Simply press the "Mode" button to switch between modes 1-4

Mode 1: Constant On Mode 2: Slow Flash Mode 3: Quick Flash Mode 4: Pulsating Flash