



INSTRUCTION GUIDE

Residential Camping Lantern

Model No.SLDL2279

PACKAGE CONTENTS

- 1 x Light Fitting
- 1 x Charger
- 1 x Solar Panel

FEATURES

1. On/Off Button
2. 10-12 hours Operation per day
3. Adjustable Handle with Hook
4. 3m connection cable on Solar Panel
5. 2 ways of charging - Solar / 240v Mains
6. 5.5v USB output for Charging of Mobile Phone
7. Colour - Blue with Stainless Steel Features

CHARGE INDICATOR LIGHTS

RED – Charging

GREEN – Fully Charged

LIGHT MODES

The lamp has 2 Light Modes:

If the **“ON/OFF”** button is pressed once while in the **“OFF”** position, the lamp will turn on to 50% brightness, If pressed again, the light will turn to 100% brightness, once more and the light will switch off.



ON/OFF Button

Charge Indicator

USB Output for Cell
Phone Charging

Solar Panel &
AC Charger
Connection
Port

IMPORTANT NOTES

- **Please ensure you place your solar panel in a location where it can achieve a minimum of 6HRS DIRECT SUNLIGHT**
- Be aware that on overcast/cloudy days, the solar panel will still charge. However, not as efficiently as a sunny day, so the battery may not reach full capacity. Therefore, your light may turn off earlier than specified
- It's best not to install the fitting underneath a street light, porch light etc. because this may stop the automatic day-night sensor triggering and result in your lights not turning on

TROUBLE SHOOTING

Phenomenon	Cause	Inspection Method	Solution
Light won't turn on	Switch hasn't been turned on	Determine what position the switch is in	Turn the switch on
	Battery has run flat	Period of rainy or cloudy weather or installation site doesn't provide enough direct sunlight	Charge the light in direct sunlight for 1-2 days then check again
The light only stays on for a short amount of time	Low Battery	1. Bad installation site for the solar panel 2. Dust or leaves are covering the panel 3. Long period of overcast weather	1. Charge the battery in direct sunlight for 1-2 days with the switch off, then check again 2. Clean the solar panel
		Battery Failure	1. Access the light and & replace battery 2. Battery has matured