



# INSTRUCTION GUIDE

## Sectional Steel Poles


Model No. SLDPOL-2.5, SLDPOL-3.5, SLDPOL-5.0

### Package Contents

1. 1 x Pole base
2. 1 x Rag Bolt Assembly
3. 1 x Pack of screws
4. Pole sections:
  - a) 2 x Pole sections (for **2.5m** Pole)
  - b) 3 x Pole sections (for **3.5m** Pole)
  - c) 4 x Pole sections (for **5.0m** Pole)

### Installation Method

1. Remove contents from packaging
2. Connect sections of poles together using the supplied screws to secure.
3. Dig hole in your desired location and install rag bolt assembly prior to concreting. **(Note: Install rag bolt assembly so that a minimum of 50mm of thread is exposed from concrete)**
4. Allow concrete to set for a minimum of 3 days before fixing pole to rag bolts.



Rag Bolt Assembly

