



QUICK START GUIDE


Straight/Flat EZ-Zip Fabric Displays



1. Assemble the poles.



2. Match symbols marked on 2 pieces together. Click together so that button nubs protrude through holes.



3. Insert vertical middle pole into holes top and bottom.



4. Slide on graphic like a pillow case on a pillow. Do not force.



5. Zip the zipper along the bottom of the graphic.



6. Notice that there is a gap on the left and right sides.



7. Insert feet into sockets exposed by the gaps. Hoist display upright. Ensure feet are perpendicular to the plane of the display.



8. Attach optional lights securely

