

G-255-1 Air Blow Nozzle

- 1) Thread 4" wand with adaptor nut onto the threaded nozzle body
- 2) Select the air tip that you want to use either 1/8" or 1/4"
- 3) Then hand tighten your selected air tip onto your threaded 4" wand
- 4) Attach your choice of 1/4" nipple quick air connect into the bottom of the nozzle body (1/4" nipple quick air connect not provided)
- 5) Connect your air hose to 1/4" nipple air quick connect
- 6) To start using pull trigger handle back towards you this will engage your air flow
- 7) Release trigger handle to stop air flow
- 8) **TO PREVENT INJURY DON'T EXCEED 125 PSI MAX**