



1. Find the “1” & “2” key (red color) on the left side of driver.
2. Use the tool to dawn or up the “1” & “2” key together to select the power.
3. Turn on the lights ,it works.

2ft 4 Wattages select

Watt/ Key	1	2
15 w	Dawn	Dawn
18 w	Up	Dawn
22 w	Dawn	Up
25 w	Up	Up

4ft 4 Wattages select

Watt/ Key	1	2
30w	Dawn	Dawn
36 w	Up	Dawn
40 w	Dawn	Up
50 w	Up	Up

8ft 4 Wattages select

Watt/ Key	1	2
60w	Dawn	Dawn
68 w	Up	Dawn
72 w	Dawn	Up
80 w	Up	Up

5000K-One step Up the key to the middle

57000- two steps Up the button to the top

57K  
↑  
50K  
↑  
40K



57K  
↓  
50K  
↓  
40K

5000K-One step Dawn the key to the middle

40000- Two steps dawn the key to the bottom



