## **Installation of Ink Cartridge**

## Note:

- 1. Please turn off the machine before installing ink cartridge.
- 2. Please take out the cartridge and keep it well with protective cap if the machine is free over 20 minutes.

Don't press hard, it will destroy the metal contact point on the bottom of cartridge. Ink cartridge is precision delicate product, don't install it with brute force.

## **Installation procedures:**

1. Place the cartridge into slot as 45 degree. The top edge of cartridge is 4mm away from machine shell.





2. Push forward the cartridge slightly from back. Let the top edge of cartridge is 1mm about away from machine shell.





Let the top edge of cartridge is 4mm about away from machine shell

3. Press the black side of ink cartridge. Let the nozzle placed in the correct position.





## Take out ink cartridge

Press the shell top with forefinger, clasp the bottom of cartridge.



