

QUICK-START GUIDE



TAKE OUT THE DEVICE AND ACCESSORIES



PUT THE FILTER ONTO THE PALLET

Soak the filter twice before use




PLUG INTO ELECTRICITY AND PRESS THE ON/OFF BUTTON


Fully wash the inner bucket twice for the first time use

USER MANUAL

1. Take out the top pallet and the filter tray.
2. Take the filter element out of the box and peel off the plastic paper on it.
3. Remove the adhesive sticker on the pump.
Don't take out the foam close to the pump and wash the foam regularly.
4. Take out the adapter, connect the bottom hub with power wire then plug in.
5. Press the on/off key once to SMART mode with the lighten-up indicator;
Short press the on/off key to switch different working modes.



INDICATOR LIGHT



1. Left light: **SMART** mode
2. Right light: **NORMAL** mode
3. Filter light: when the light turns to **Red**, it reminds you to change a new filter.
4. The **blue light** in the bucket will be on when there's lacking of water



CUSTOMER SERVICE




GET MORE INFORMATION
WWW.PETKIT.COM

QUESTIONS / COMMENTS

info@petkit.com
+86 21 51355906
Skype: petkit.shanghai

Please download App "PETKIT" in
App Store or Google Play
to join in the PETKIT community and enjoy more.





EVERSWEET

SMART PET DRINKING FOUNTAIN



NOTES

Please pay attention to the following advices to prevent the safety issues.

1. The device is for indoor use only.
2. Please cut off the power when you clean the device
3. Please ensure the pets not bite the power wire, otherwise, it may lead to electric leakage.
4. When the children or elderly use the device, please make sure they use it under the proper guidance.
5. Please place the device on the floor or flat ground to make it work properly.

