

正面

QUICK-START GUIDE



TAKE OUT THE DEVICE AND ACCESSORIES




PUT THE FILTER ONTO THE PALLET
Soak the filter twice before use



PLUG INTO ELECTRICITY AND PRESS THE ON/OFF BUTTON
Fully wash the inner bucket twice for the first time use

USER MANUAL

1. Take out the top pallet and the filter tray.
2. Take the filter element out of the box and peel off the plastic paper on it.
3. Remove the adhesive sticker on the pump.
Don't take out the foam close to the pump and wash the foam regularly.
4. Take out the adapter, connect the bottom hub with power wire then plug in.
5. Press the on/off key once to SMART mode with the lit up indicator. Short press the on/off key to switch different working modes.



INDICATOR LIGHT



1. Left light: **SMART** mode
2. Right light: **NORMAL** mode
3. Filter light: when the light turns to **Red**, it reminds you to change a new filter.
4. The **blue light** in the bucket will be on when there's lacking of water

CUSTOMER SERVICE



GET MORE INFORMATION
WWW.PETKIT.COM

QUESTIONS / COMMENTS
info@petkit.com
+86 21 51355906
Skype:petkit.shanghai

Please download App "PETKIT" in App Store or Google Play to join in the PETKIT community and enjoy more.



-01-

背面



NOTES

Please pay attention to the following advices to prevent the safety issues.

1. The device is for indoor use only.
2. Please cut off the power when you clean the device.
3. Please do not allow your pet to chew the wire, if any damage to the wire occurs please discontinue use.
4. When children or the elderly use the device, please make sure they use under supervision.
5. When the device is in use please ensure it is filled with water and is placed on an even surface.



-01-

瓦楞纸K=A, 厚度2mm
尺寸: 172mm x 172mm
实际刀模以图纸曲线为准



项目名称	W1	部件	瓦楞纸盒内衬纸板 + 说明书刀模图	版本	v1.1 英文版	日期	20160729
设计师				审核			