



Model	A1	A2	X1	X2	Y1	Y2	C1	C2	D	H
PDD 80Lx80R	800	800	785-800	785-800	780-795	780-795	227-242	227-242	405	2005
PDD 80Lx90R	800	900	785-800	885-900	780-795	880-895	227-242	327-342	488	2005
PDD 80Lx100R	800	1000	785-800	985-1000	780-795	980-995	227-242	427-442	488	2005
PDD 80Lx120R	800	1200	785-800	1185-1200	780-795	1180-1195	227-242	627-642	488	2005
PDD 90Lx80R	900	800	885-900	785-800	880-895	780-795	327-342	227-242	488	2005
PDD 90Lx90R	900	900	885-900	885-900	880-895	880-895	327-342	327-342	570	2005
PDD 90Lx100R	900	1000	885-900	985-1000	880-895	980-995	327-342	427-442	570	2005
PDD 90Lx120R	900	1200	885-900	1185-1200	880-895	1180-1195	327-342	627-642	570	2005
PDD 100Lx80R	1000	800	985-1000	785-800	980-995	780-795	427-442	227-242	488	2005
PDD 100Lx90R	1000	900	985-1000	885-900	980-995	880-895	427-442	327-342	570	2005
PDD 100Lx100R	1000	1000	985-1000	985-1000	980-995	980-995	427-442	427-442	570	2005
PDD 120Lx80R	1200	800	1185-1200	785-800	1180-1195	780-795	627-642	227-242	488	2005
PDD 120Lx90R	1200	900	1185-1200	885-900	1180-1195	880-895	627-642	327-342	570	2005

