



















HAVE A QUESTION? GIVE US A CALL. 1-800-363-0219 VOUS AVEZ UNE QUESTION? APPELEZ-NOUS AU 1-800-363-0219


Thank you for purchasing this product from Mazin Furniture. Please take the time to read and follow the instructions below. Check that you have all parts and hardware before assembly. Parts apparently missing are often found in the packing materials. If you do not have all the parts listed, have your dealer contact us and they will be sent to you immediately.

Merci d'avoir acheté ce produit de Mazin Furniture. Veuillez lire et suivre les instructions ci-dessous. Vérifiez avant le montage que vous avez toutes les pièces et fixations. Les pièces qui semblent manquer se trouvent souvent dans les matériaux d'emballage. Si vous n'avez pas toutes les pièces de la liste, demandez à votre détaillant et nous vous les enverrons immédiatement.


NO		HARDWARE LIST /LISTE DE QUINCAILLERIE		NO		PARTS LIST / LISTE DE PIÈCES	
A		Hex Nut / Ecrou	4	1		Wall Side Table	1
B		Bolt / Boulon	14	2		Wall Side Table	2
C		Lock Washer / Rondelle d'arrêt	18	3		Wall Side Table	1
D		Flat Washer / Rondelle Plate 1mm	14	4		Table Top / Dessus de table	1
E		Flat Washer / Rondelle Plate 2mm	4				
F		Screw / Vis	4	5		Leg / Pied	4
G		Hinge / Charnière	1	6		Upper Panel / Panneau Superieur	1
H		Allen Wrench / Clé Allen	1	7		Lower Panel / Panneau Inferieur	1
K		Wrench / Clé	1				

DO NOT TIGHTEN BOLTS UNTIL COMPLETELY ASSEMBLED. NE PAS SERRER LES BOULONS JUSQU'À CE QUE LE MONTAGE SOIT COMPLETMENT TERMINE


STEP 1 / ETAPE 1



STEP 2 / ETAPE 2



STEP 3 / ETAPE 3



STEP 4 / ETAPE 4

