

## ! Stay safe

Before using the Snow Foam Lance Plus, please check your pressure washer's pressure range and flow rate.

After each use, flush the Snow Foam Lance Plus with fresh water for 30 seconds to clear out leftover solution. This prevents the stainless steel mesh within from clogging up which would reduce foaming effectiveness over time.

The installed 1.25mm orifice is effective for pressure washers with ratings as low as 1300 PSI (90 Bar). For pressure washers below this rating a 1.1mm orifice is included to increase the foaming capacity of the lance.

If your pressure washer is rated over 2200 PSI (150 Bar), please do not use this lance.



# Snow Foam Lance *Plus*



[detailstore.com.au](http://detailstore.com.au)

clean  
skin.

## ? How to use

- 1** Fill the bottle with your preferred snow foam solution. If using the Apex Customs Foamstar, please dilute at a ratio of 1:10 or 100ml solution to 1,000ml of water.
- 2** Assemble the adapter and tube to the body of the foam lance. Connect the body to the bottle and attach the entire foam lance to your pressure washer.
- 3** Adjust the top dial to change your foaming ratios and the nozzle to alter the spray angle (full 360° angle).
- 4** Foam up your vehicle from top to bottom and allow the foam solution to dwell on the surface (1 to 3 minutes depending on solution).
- 5** Rinse off or commence two-bucket washing.

## Tech specs



**Max pressure**  
2200 PSI (150 bar)



**Max flow**  
21 Litres Per Minute



**Max temperature**  
60°C



**Ø nozzle**  
1.25mm

## Spare parts

- 1x 1.1mm orifice nozzle
- 1x Stainless steel mesh filter

