

This paper itself is an instruction of how to set. This instruction paper helps you to hang GRAN BOARD on the wall by taping it.

2

Tape this instruction to the wall


Tape this instruction to the wall

2




1

Measure 2m from the floor to this line



1

Measure 2m from the floor to this line



3

Put screws on the wall

### Set GRAN BOARD

1

Set this dotted line on the instruction paper to be 2.0m from the floor.

※Please make sure both ends of this line to become 2.0m to keep the balance.

2


After setting a position, fix the instruction on the wall with tape after setting in position.

※Make sure don't let the instruction paper be slack. Otherwise screw might be set in inaccurate position. Please fix the paper with tape at all sides if it is slack. Be careful to take off adhesive tape for left tape and the ripped instruction paper.

3

Put screws at the cross each three points over the instruction paper.

※Don't put screws into the wall completely. Please make 6.0mm space between a screw head and the wall. Don't put screws into PLASTER wall. GRAN BOARD can be fallen from the wall.




4

Please take this instruction off kindly.


※The back of this instruction is a rule book. When taking it off, please start at the parts that put screws in.

#### Attention of Setting GRAN BOARD

Please set GRAN BOARD not to distort the back cover. Setting GRAN BOARD with an inaccurate size partition causes distortion at the back cover. It might damage to sensor inside and cause malfunction and troubles.




### DARTS AREA SIZE



Don't throw darts at person and animals. There is a danger of a wound, or being blind.

Please don't play around children. If a dartboard is fallen down, it is dangerous.



3

Put screws on the wall



3

Put screws on the wall

## Dartboard and Scores

**TARGET NUMBER&AREA**  
This number is added as a score in this area.

**CHANGE BUTTON**  
Finish a round, tap this button and change to the next.

**LED LAMP**  
Show Bluetooth status  
Blinking red : Standby  
Solid green : Connected

**POWER SWITCH**

**DOUBLE AREA**  
Here is double the number added to a score.

**TRIPLE AREA**  
Here is triple the number added to a score.

**SINGLE AREA**  
The number is added to a score.

**BULL (center)**  
Here is 50 points added to a score.

GRANBOARD3 will go into sleep mode if any of operations haven't done for 10 minutes when using USB. Press the change button to restore from sleep mode.

## How to throw darts

- 1 SETUP**  
Set (a dart) at the front of a face. Refer to the picture.
- 2 TAKE BACK**  
Fold up arms and get closer toward a face.
- 3 THROW**  
Swing arms straight and throw a dart.

You can throw three darts each round. Don't forget it as basic of darts.

## 3 Steps to Start Darts Game


### STEP1 Preparing the app and registering an account

#### Download App from Stores in a Smart Phone or Tablet

App Name **GRAN BOARD**  
(Free to download)  
アプリ内課金があります

Apple, Apple logo, iPad, iPhone, iPod Touch are trademarks registered in the U.S and other countries. Apple Store is a service mark of Apple Inc.  
'Google Play', 'Google Play Logo', and 'Android' are trademarks or registered trademarks.

#### After Successfully Download App, Prepare for Making a New Account.



Enter Email, Gran ID and Password for a New account

※Please keep email address and password because they are required to log in when re-install the app in other device or share one account with others.

### STEP2 Create a player card

#### Make Player Card to Manage Play Data

**Setting Player Icon**  
Tap on the camera icon and it brings you to camera roll. Select your favorite image for your player icon.

**Setting Player Name**  
Register your player name which appears on your player card (Background is also customizable from MY PAGE)

Various of convenience features are available after you register a player card.

Manage Play Data Details | Customize Game Screen | Online Play

Communicate with darts friends | Send messages to other players | Check world rankings

### STEP3 Starting GRANBOARD / Bluetooth Connection

#### Start GRANBOARD and Connect The App to Your Device

\* USB power supply is required for LED effects. (MicroUSB)

**Start GRANBOARD with USB**  
The Micro USB port is located directly at bottom of the board. Please plug in the USB cable there.

**Start GRANBOARD with AA Batteries**  
\* LED effects will not illuminate  
It is able to play games as normally with two AA battery for a couple month.

LED light beside the power switch flashes in red as you turn the power on. The app connects to the board automatically, then LED light becomes green. Setting is completed when the app successfully connected to the board.

In the case of connection could not be done successfully, follow the connecting navigation which you can find in HELP on the bottom of home screen.

\*AA batteries are sold separately. Do not mix batteries, use different batteries, mixed alkaline batteries, and manganese batteries. They may cause leakage or rupture.


#### Attention

**Attention to Safety** ●Don't throw darts at person and animals. There is a danger of a wound, or being blind. ●Please don't play around children. If a dartboard is fallen down, it is dangerous. ●The point of darts is like a needle on purpose, so please don't use without darts game. ●Be careful of an electric shock. Please don't touch with wet hands. ●Please hang a dartboard on solid wall to hold. ●If hanging a dartboard on weak wall like plaster, There is a danger of the fall down of dartboard. ●Please make sure that there is no person, animal, and something easy to break around a dartboard when throwing darts. ●After playing darts, please put darts at places where children can't touch.

**Attention to Play** ●It requires preparing iOS or Android smartphones or tablets for darts game. You can't play only with GRAN BOARD. ●Please make sure whether your devices are compatible with GRAN BOARD App. ●GRAN BOARD is only available for soft tip darts. Don't use steel tip darts. It causes damages and troubles of GRAN BOARD. ●The use of heavy darts is a cause of damages and deterioration. ●The wall might be hurt if you miss throwing darts and hit at the wall. ●Please don't do baseball throwing. GRAN BOARD becomes damaged, broken, or deformation. ●Don't use and put GRAN BOARD at places where it is hot, humid, and under the sunlight. ●GRAN BOARD is not waterproof. Please don't get GRAN BOARD wet. ●GRAN BOARD is basically for the home use. Please don't use with the business use.


## O1 GAME

### The Most Standard and Popular Darts Game



Max Rounds 20 rounds

1 round 3 darts



O1 GAME is a very simple game. At the start of a game, choose one from these numbers (Start Number).

Throw three darts each round. Points earned are deducted from Start Number. A game is finished when Start Number is reached exactly at zero. If you make the number under zero, it is considered as BUST which gets back before throwing in a round. If you can't finish the number until Round 20, the game is over.

When playing with some players, a player who reaches at zero at first is a winner. Let's try how fast you can finish it when playing alone. Tap O1 GAME and choose a number you want to play.

You can play this game from the screen below.


**GAME SELECT** Select the button.

Select O1 GAME and it will be displayed on the right. Please select the game screen of your choice.

Application top screen | Game select screen



## STANDARD CRICKET

### Use Tactics to Attack and Defend! Domination Game!



Max Rounds 20 rounds

1 round 3 darts



STANDARD CRICKET is a tactics game as popular as O1 GAME. This game uses seven areas on the board. [ 20 / 19 / 18 / 17 / 16 / 15 / BULL ]

One single shot is counted as one mark [ / ], two as two marks [ X ], and three as three marks [ X ]. Then the area becomes yours. One Triple shot is considered as three marks. After making an area turned to yours, earn points when hitting there.

In a match, an opponent marks three in your area. Then it becomes closed and you can't earn points there.

A player who occupies all seven areas and has the highest score is a winner. Add points or close an opponent area. Switch attack or defense to get a win.

You can play this game from the screen below.

**GAME SELECT** Select the button.

Select CRICKET and appear on the right side. Please select the screen of STANDARD CR.

Application top screen | Game select screen



## COUNT UP

### Shoot at Bull for the Highest Score!



Rounds 8 rounds

1 round 3 darts



COUNT UP is very simple, but also interesting. Three darts a round, and all eight rounds. This is a game of how many points you can earn with total 24 darts.

Even though playing with some player, all players throw 24 darts in total eight rounds. A player who has the highest score is a winner.

Two Circle at the center of the board marks 50 points. How many times you shoot at the center is going to be a key to get a win in this game

If you shoot all 24 darts at the center, total is 1200 points. For beginners, why don't you mark 500 at first?

You can play this game from the screen below.

**GAME SELECT** Select the button.

Select PRACTICE and display on the right side. Please select COUNT UP game screen.

Application top screen | Game select screen

## GRAN OFFICIAL WEBSITE

[www.gran-darts.com](http://www.gran-darts.com)

### Warranty

**Warranty Content** if GRAN BOARD is broken within warranty period even though using appropriately, please ask a shop you purchased, or Support Center.  
(Please keep the receipt. We require you to show us.)

Please be careful. You CAN NOT receive supports if losing the receipt

Warranty Period 3 month after the purchase

Name \_\_\_\_\_  
Phone Number \_\_\_\_\_  
Email Address \_\_\_\_\_  
Address \_\_\_\_\_